# Installation Requirements

## **Tools and Parts**

Parts supplied Removing the packaging

 $\triangle$  CAUTION Remove carton carefully, wear gloves to protect against sharp edges.

Remove the protective film covering the product before putting into operation.

- Hood canopy assembly with blower and LED lamps already installed.
- 6" (15.2 cm) round air transition
- Duct covers
- Hardware bag with:

Part	Qty	Part	Qty
5x45 mm	6	5.4x75 mm screws (for 10x60 mm wall anchors)	4
8x40 mm	2	■■↓ Torx 10 adapter	1
3.5x9.5 mm	2	Duct cover bracket	1
40000) 4x8 mm	4	Mounting template	1
10 x 60 mm	4		-

### Tools/Materials required

- Drill with 11/4" (3.2 cm), 1/8" (3.2 mm), and 1/16" (4,8 mm) drill bits
- Wire stripper or utility knife
- Tape measure or ruler
- Caulking gun and weatherproof caulking compound
- Vent clamps
- · Jigsaw or keyhole saw
- Flat-blade screwdriver
- Metal snips
- Phillips & Torx 20 screwdriver


# Parts needed

- · Home power supply cable
- . 1/2" (12.7 mm) UL listed or CSA approved strain relief
- · 3 UL listed wire connectors

# For vented installations, you will also need:

- 1 wall or roof cap
- Metal vent system

#### **Dimensions and Clearances**



	NK30K7000WS NK30K7000WG	NK36K7000WS NK36K7000WG	
Α	30" (76 cm)	36" (91.2 cm)	
В	19¹½́6" (50 cm)		
C*	max. 43 <sup>11</sup> / <sub>2</sub> 2" (110.1 cm) min. 29// <sub>1</sub> ε" (73.8 cm)		
D**	max. 39³⅓₄" (100.3 cm) min. 25²¾" (64.5 cm)		
E	6" (15.24 cm)		
F	10 <sup>19</sup> / <sub>52</sub> " (26.9 cm)		
G	13¾(" (33.2 cm)		
Н	2 <sup>23</sup> / <sub>64</sub> " (6 cm)		

<sup>\*</sup>For non-vented (recirculating installations)

<sup>\*\*</sup>For vented installations