

# Wire Shelving

#5129786 #5141840  
#5129787 #5141841  
#5141839 #5141842

## Method 1 - with Vertical Standards




Fig. 1

### 1. Install Vertical Standards

The top rail is installed to support vertical standards. Install standards by hooking the top into the rail at an angle with the standard bottom away from wall and then let standard fall parallel with the wall to engage into the rail. **Fig. 1**




Fig. 2

### 2. Secure Vertical Standards

Standard must be screwed to the wall in addition from hanging on the top rail. Screw to studs or use anchors that are applicable to drywall or masonry. **Fig. 2**






Fig. 3


### 3. Install Brackets

Brackets can be installed into standards at desired heights to support shelves.

Insert bracket into rectangular holes with the front raised, then drop front of bracket and tap downward to secure. **Fig. 3**



**Fig. 6**



**Fig. 5**


#### **4. Install Shelves**

Install end caps by pushing caps onto ends of wire shelf before putting shelf in place. **Fig. 4**

Place the shelf on installed brackets, hooking the front of the shelf over the end of the brackets. End of bracket will protrude through the front of the wire shelf. **Fig. 5**

Push shelf backwards into the shelf hooks on the rear of brackets. Pull the shelf forward to lock shelf into place. **Fig. 6**


Note: Shelves can be cut to size with hacksaw. Make cut on side of shelf that is facing wall. Cut edge will be concealed by shelf caps.




**Fig. 4**

## **Method 2 - with Shelf Support Brackets**

**Fig. 1**



**Fig. 2**




#### **1. Install Wall Clips**

Find desired shelf height and mark line using level, then locate studs with stud finder. Install 1 clip at least every 12 inches and at each end of shelf.

Screwing clip into stud is preferred, use pin anchor when mounting between studs, into drywall. **Fig. 1**


Insert back of shelf into the installed wall clips. **Fig. 2**



**Fig. 3**

## 2. Install Support Brackets

Again, locate studs. Install a support bracket 3 inches from each end of shelf and no wider than 36 inches apart. Mounting to stud is preferred. Hook support bracket onto top horizontal frame with the fork around a grid wire. **Fig. 3**



## 3. Secure Support Brackets

Push the bracket bottom back toward the wall which locks the bracket fork into the shelf. Be sure the self is level. Secure the bottom of the support brackets to the wall. Screwing directly to stud is preferred. Use pin anchor when mounting between studs, into drywall.

### **Fig. 4**

Pin anchor is supplied with brackets.