













Assembly Instructions

Caution: You must read this before you proceed




Care & Maintenance

-  ● Not for commercial use. For residential use only.
 -  ● Furniture may scratch floors. We recommend using furniture pads to protect your floors.
 -  ● Do not put hot items directly on furniture surface.
 -  ● Do not clean furniture with harsh cleansers or polish.
 -  ● Do not place furniture under direct sunlight.
 -  ● Do not place furniture near heating or cooling vents.
 -  ● Do not write on furniture without a padded barrier to protect the surface.
 -  ● Do not place furniture outside . For indoor use only.
 -  ● Stains may be removed with mild soap solution and damp cloth.
 -  ● Children should not climb or jump on the furniture.
-
-  ● Dust and pick-up spills using a clean, non-colored, lint-free cloth.

RECLINER



Parts List


Label	Picture	Description	QTY
A		Chair Backrest	1
B		Chair Base	1
C		Leg	4

Assembly Preparation

Before Beginning Assembly:



X1



X1



X4



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-


Assembly Steps

Overview




This Chair has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

Step 1




Position the Chair on its back, as shown.(Perferrably on a surface that won't scratch the upholstery.)
Open the inner box and take out the 4 Leg(C) provided, then remove the plastic covers of Legs.

Step 2




Keep the Chair Base(B) in the same position.
Install the Legs(C) with the washer ring at the bottom of the Chair on the threaded stem. Tighten by turning the Leg clockwise, DO NOT OVER TIGHTEN.

Step 3





With assistance from your adult partner, hold up the fully assembled Backrest(A) ,stand behind the Chair.
Insert the pre-attached Metal Bracket on the sides of the Chair Backrest(B) into the pre-attached slide lock gadget on the Chair Base(B) as shown above.
Firmly but gently, push the Chair Backrest(A) downwards **until the Backrest(A) is fully slotted and locked into position.**

Step 4



Smooth down the fabric flap on the Chair Backrest.
Run your hands down both sides of the flap, from top to bottom, allowing the magic tape to adhere to the flap under the seat of the chair. Your Recliner is ready for use.

Step 5




Your Recliner is ready for use.

This Recliner can only be used on a flat, level surface.

Note: Place the Chair on a **LEVEL SURFACE** to check for wobbling. Adjust the levelers on the legs to ensure Chair stability..

Disassembly



Disassembly Note: Open the flap on the Chair Backrest(A), use a screwdriver (Don't use fingers) pressing outward on the metal ear on the pre-attached Metal Bracket on one side of the Chair Backrest(B).

With assistance of you adult partner to keep the Chair Base(B) in place, pull out the Chair Backrest(A) upward at the same time, repeat the same step for another side.

Then the Chair Backrest(A) can be taken out.


User Instructions.

Recliner Chair

Please read the Instruction Manual below carefully before use.

This is a Recliner Chair. At anytime in a reclined seat position or in the upright position. You may enjoy the rocking motion by using your body weight in a back-front rocking motion.


Supervise children, when in use of this Recliner.



Always leave the chair in an upright and closed position after use.
Keep hands and feet clear of the footrest mechanism and any gaps.
Do not allow children to play on the chair.
Do not lean to side to pick up anything while sitting on the chair.
Do not sit on the arms.
Do not stand up when the recliner open.
Only the occupant should operate the chair.

To get into a reclined posture - To Recline backrest

Sit into the seat.
Place your feet apart .
Place your left and right arm onto the armrest.
Synchronise a backward push with your arms.
Use your body weight and push backwards into the seat into a fully reclined position.



To get out of chair - move Seatback into Upright Position

Tilt your body weight slightly forward and upwards.
The seat back will come up to an upright position.
Where necessary, use either your arms help lift- push yourself out of the seat.

