# ASSEMBLY INSTRUCTIONS 24 INCH BATH VANITY - COMBO



Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware.

Compare with the parts list to be sure all parts are present.

"DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED"



- \* Use of power tool to assemble this product will invalidate any claim and damage this product making unsafe!!
- damage this product making unsafe !!!

  \* Please assemble on a clean soft surface to avoid damage.











(Not included)



**IMPORTANT:** 

PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY

Thank you for buying our products.

Please read the installation manual carefully before installation,

we need you to follow the instructions on the accessories and hardware

step by step assembly complete, our instructions are very detailed.

Products are environmentally friendly products,

Please rest assured that you do not soak in water, do not place very heavy items,

do not malicious push and pull,

if you have any problems in the process of assembly and use, please contact us.

Thank you again for your purchase of our products,

I wish you a happy life.

## **Before Installation**


#### Important - Please read these instructions fully before starting assembly


Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.

- . We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
- . Please do not over tighten screws or bolts until the assembly is completed.
- . Keep children and animal away from the work area, small parts could choke if swallowed.
- . Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

If you find that you have any trouble with assembly or missing or damaged parts please contact the seller.


#### **Cam Lock Assembly Instructions**






# Part List - N725P280602 1 2 Side Panel (R) - 1pc Side Panel (L) - 1pc 3 4 Mid Panel - 1pc Top Panel Rear - 1pc 5 6 Mid Panel Rear - 1pc Top + Bottom Panel - 2pcs 7 8 Bottom Panel Rear - 1pc Bottom Panel - 1pc 10 9 Cabinet Door - 1pc Adjustable Shelf - 1pc 11 12 Drawer Back Panel (A) - 1pc Drawer Face (A) - 1pc 13 14 Drawer Side Panel Left (A) - 1pc Drawer Side Panel Right (A) - 1pc


#### Part List - N725P280602





# Hardware List - N725P280602


Α	В	С
		<i>€</i> ]mmmm>
ø6x35mm	ø14.5x12mm	ø8xø4x32mm
Three in one bolts(19pcs)	Three in one lock(19pcs)	Round head screw(26pcs)
D	E ⊕	Ø8x30mm
Damping hinge (2pcs)	Flat head screw(12pcs)	Wood dowel(23pcs)
<b>G</b>	Н	I
ø6x30mm		
Wood dowel(16pcs)	Laminate pad - 4pcs	Handle (4pcs)
J	K	L
		(S)
ø5/32"x18mm	ø5/32"x22mm	ø5/32"x30mm
Handle screw (1pc)	Handle screw (1pc)	Handle screw (2pcs)
M	N	0
ø13x1/4"x28mm	ø1/4"x16x1mm	4mm
Hex-Head bolts(2pcs)	Washer(2pcs)	Allen key(1pc)
Anti fall hardware(2set)		



























## **STEP: 14**






# HINGE ADJUSTMENTS



# 1 Sideways / Tilt adjustment


Turn the screw clockwise to move the door further away from the side of the cabinet anticlockwise to move the door closer to the side of the cabinet



# 2 4 Height adjustment

While supporting the weight of the door, turn the screws

clockwise to move the door up anticlockwise to move the door down



## 3 Forward and back adjustment

If the gap between the back of the door and the cabinet is too small, and the door may not close fully. Turn the screw

**clockwise** to decrease the gap between the door and the cabinet

anticlockwise to increase the gap between the door and the cabinet

