

# Assembly Instructions

Island Light SKU# TH-SF0106/TH-SF0107

INSTRUCTIONS PERTAINING TO RISK OF FIRE OR INJURY TO PERSONS READ ALL INSTRUCTIONS

## IMPORTANT SAFETY INSTRUCTIONS SAVE THESE INSTRUCTIONS

### SAFETY PRECAUTIONS:

1. TURN OFF ELECTRICAL POWER BEFORE STARTING INSTALLATION OF LIGHT FIXTURE.
2. WIRING SUPPLIES AS REQUIRED BY LOCAL ELECTRICAL CODE.
3. THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.
4. TO CLEAN THE FIXTURE, TURN OFF THE POWER, WAIT FOR IT TO COOL, AND WIPE THE FIXTURE WITH A CLEAN, SOFT CLOTH. NEVER SPRAY CLEANER DIRECTLY ONTO THE FIXTURE.

**NOTE:** Product may not look exactly as shown in figures.

**CAUTION:** Inspect the wire insulation for any cuts, abrasions, or exposed copper that may have resulted during shipping. If there is a defect in the wire, do not attempt installation.



This fixture has been rated for up to 60-watt maximum TYPE A bulbs or 13-watt compact fluorescent light bulbs or 9-watt LED bulbs . To avoid the risk of fire, do not exceed the recommended wattage.

This product is safety listed for dry locations.

This product may be dimmed with a standard incandescent dimmer.

### Assembly Steps:

1. J, K → O
2. N, F → J
3. D1, C → A
4. L, M → B
5. E, F → D
6. Q → P



Part Included		
Code	Part Description	QTY
A	Junction Box	0
C	Universal Mounting Bracket	1
D	Mounting Screws	3
E	Decorative Nuts	2
F	Canopy	1
J	6" rods	2
K	12" rods	6
L	Wires	3
M	Leading Wires	0
N	Hex Nuts	2
O	Frame	1
P	Socket	5
Q	Light Bulbs	0

Hardware included		
B	Wire Nuts	4
D1	Bolts	3

### Trouble Shooting

Problem	Possible Cause	Solution
The bulb will not light.	The power is OFF.	Ensure the power supply is ON.
	There is a faulty wire connection.	Check the wiring.
	The circuit breaker is OFF.	Ensure the circuit breaker is in the ON position.
The fuse blows or circuit breaker trips when the light is turned ON.	There are crossed wires or the power wire is grounding out.	Check the wire connections. Contact a qualified electrician.