

NOTICE

*Please make sure that you have all parts indicated and they are in good condition before you begin assembly of this item. Refer to part list and hardware list below for guidance.

*This item should be assembled on a soft surface to prevent scratching the finish during assembly.

*This item may require periodic tightening.

*If you are having difficulty, our friendly Customer Care team is always here to help. Please email customersupport@safavieh.com

PREPARATION

*Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.

*If any part is missing or damaged, do not attempt to assemble the product.


*Estimated Assembly Time: 60 minutes.

*Tools Required for Assembly (included): Allen Key

CARE AND MAINTENANCE

Always use felt pads under all articles to prevent discoloration or softening of the lacquer. Plastic and rubber bases on items can discolor wood. Wipe up spills immediately and avoid common hazards such as hot dishes, harsh solvents and abrasives. Cleaning should be done with a soft lint free cotton cloth dampened with water or furniture polish. On highly used surfaces we recommend applying a quality paste wax which should be used on a regular basis to provide additional protection from scratches and spills. How often you apply the wax depends on how much wear the furniture receives.


Part List



 **SAFAVIEH**
FURNITURE

Model# COF9600

Product Dimensions: 46"Wx23"Dx16"H











WARNING :

WEIGHT CAPACITY: 75 LBS.

Warning : Do not stand on coffee table.

Warning : Do not over torque bolts.

Hardware List

HW1x6  Ø 6 x 35 mm	HW2x6  Ø 15 mm	HW3x23  Ø 8 x 30 mm	HW4x7  M 7 x 50 mm	HW5x1  L 4
HW6x24  M 4 x 16 mm	HW7x5  25 x 25 mm	HW8x4 	HW9x4 	HW10x4 
HW11x4 	HW12x10  M 6.4 x 53 mm	HW13x4  Ø 8 mm	HW14x6  Ø 15 mm	HW15x1 
HW BC410x4 				

Part List & HW For Multi-Box Items

Piece	Description	Qty
A	Top Board	1
B	Bottom Board	1
C	Side Board	2
D	Center Board	1
E	Support Leg 1	2
F	Support Leg 2	2
G	Leg	4
H	Center Leg	1
I	Frame Door	2

Piece	Description	Qty
HW1	Cambolt	6
HW2	CamLock	6
HW3	Dowel	23
HW4	Screw M 7 x 50 mm	7
HW5	Allen Key	1
HW6	Screw M 4 x 16 mm	24
HW7	Floor Protector	5
HW8	Spring Washer	4
HW9	Nut	4
HW10	Pin Sliding Top	4
HW 11	Pin Sliding Bottom	4
HW12	Screw M 6.4 x 53 mm	10
HW13	Bumper	4
HW14	Screw Cap	6
HW15	Wrench	1
HW BC410	Corner Brace	4

PREPARATION


*Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.

*If any part is missing or damaged, do not attempt to assemble the product.


*Estimated Assembly Time: 60 minutes.

*Tools Required for Assembly (included): Allen Key


*If you are having difficulty, our friendly Customer Care team is always here to help. Please email customersupport@safavieh.com




STEP1: Insert Cambolt (HW1) into Top Board (A)
Insert Dowel (HW3) into Side Board (C), and Center Board (D)



STEP2: Attach Side Board (C) ,Center Board (D) into Top Board (A).
Insert Camlock (HW2) then tighten using screwdriver.
Put Screw Cover (HW14) over the camlock.



STEP3: Insert Dowel (HW3) into Center Leg (H).
Attach Center Leg (H) to the Bottom Board (B).
Secure with Screw M7x50 (HW4), tighten screws using Allen Key (HW5)



STEP4: Attach Bottom Board (B) as figure. and secure with
Screw M7x50 (HW4), tighten screws using Allen Key (HW5)

PREPARATION





*Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.

*If any part is missing or damaged, do not attempt to assemble the product.

*Estimated Assembly Time: 60 minutes.

*Tools Required for Assembly (included): Allen Key

*If you are having difficulty, our friendly Customer Care team is always here to help. Please email customersupport@safavieh.com



PREPARATION


*Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.

*If any part is missing or damaged, do not attempt to assemble the product.


*Estimated Assembly Time: 60 minutes.

*Tools Required for Assembly (included): Allen Key


*If you are having difficulty, our friendly Customer Care team is always here to help. Please email customersupport@safavieh.com




STEP9: Bring the assembled Support Leg and insert into Bottom Board.



STEP11: Insert Screw M6.4 x 53 (HW12) and tighten using Allen Key (HW5).




STEP10: Remove plastic cap from Legs. Insert the bolt of the Leg (G) into hole of corner brace as shown in figure. Insert Spring Washer (HW8) first into the hanger bolt of leg, then followed by Nut (HW9), tighten all the nuts using provided Wrench (HW15). Ensure that all legs have been tightened then tighten all screws on the corner brace.




STEP12: Peel the back paper of Bumper (HW13) then place on both frame door, position as shown in figure above. Insert Top Pin Sliding (HW10) and Bottom Pin Sliding (HW11) on both end of frame door (I) as specified position in the figure.

PREPARATION

- *Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.
- *If any part is missing or damaged, do not attempt to assemble the product.
- *Estimated Assembly Time: 60 minutes.
- *Tools Required for Assembly (included): Allen Key
- *If you are having difficulty, our friendly Customer Care team is always here to help. Please email customersupport@safavieh.com



STEP13: Hold the frame door with position of the Top pin shown facing upward. Put the frame door by inserting it to the upper groove on Top Board (1), then place the lower part aligned into the groove on bottom board (2). Repeat this step for the other door. Slide the item's doors left and right to ensure the doors have been placed properly in the provided track.



STEP14: Assembly is completed.