


If you have any questions, please feel  
free to contact us.  
Email: [lowesteam@aminalife.com](mailto:lowesteam@aminalife.com)

# ASSEMBLY INSRTRUCTION


## Hall Tree




### Dimensions

Width-59.05inch  
Depth-15.74inch  
Height-77.95inch

### Approximate Assembly Time



### People Required to Assemble





## Safety and Care Advice

**Important – Please read these instructions fully before starting assembly**

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



- To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

### Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.


### Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure that all bolts and fittings are tightened properly.

**WARNING**  
**In order to help prevent overturning –**  
**please follow these instructions**









To help prevent product toppling over please follow the below steps:-

Use the anti tip strap or wall fixing method provided (if applicable)  
Do not allow children to climb or hang on the furniture  
Do not open more than one drawer at a time  
Do not place heavy items in the top drawers  
Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose




















# There are 2 boxes of this product



















Box 1 :WF311318

			
① x 1	② x 1	④ x 1	⑥ x 1
			
⑦ x 1	⑧ x 1	①⑥ x 1	①⑦ x 2


Box 2 :WF311319

			
③ x 1	⑤ x 2	⑨ x 1	⑩ x 1
			
⑪ x 1	⑫ x 1	⑬ x 1	⑭ x 1
			
⑮ x 1	⑱ x 1	⑲ x 1	⑳ x 1
			
⑳ x 1	㉒ x 1	㉓ x 1	㉔ x 1
			
㉕ x 1			

Box 2 :WF311319

 Φ6x35mm A x 43+2	 Φ15x10mm B x 43+2	 Φ6x30mm C x 55+2	 D x6	 Φ5x6x14mm E x4+1	 Φ4x14mm F x36+2
 Φ4x40mm G x38+2	 Hx4	 Φ4x18mm I x3	 J x3	 Φ4x25mm K x3+1	 Φ4x12mm L x18+2
 M x2	 Φ6x30mm N x2	 Φ4x20mm O x6+1	 P x3	 Φ4x10mm Q x6+1	 Φ4x14mm R x22+2

Tools required




# Using Camlocks

## Step 1

Connect the male camlock as directed in the assembly instructions using a screwdriver.

1


DO NOT OVER TIGHTEN.  
NE PAS SERRER EXCESSIVEMENT.



## Step 2

Push the male camlock into the entry hole.

2




## Step 3

Insert the female camlock as shown in the instruction.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.

3




## Step 4

Turn the female camlock clockwise with a screwdriver.


You should feel a click when the camlock is locked in place.

The joint is now secure.


4



## Step 1




## Step 2












Step 3






Step 4




# Step 5






# Step 6



Step 7








# Step 8




 $\Phi 15 \times 10 \text{mm}$ <b>B x 8</b>	 $\Phi 6 \times 30 \text{mm}$ <b>C x 4</b>	 $\Phi 4 \times 40 \text{mm}$ <b>G x 2</b>
--	---	---

# Step 9







 <b>Φ15x10mm</b> <b>B x 7</b>	 <b>Φ6x30mm</b> <b>C x 5</b>
--	---




## Step 10






Raise the sides of board 9 and board 7 which are near board 8, align board 8, and put them down together.



Step 11




Step 12








Step 13




# Step 14




# Step 15



Step 16











Step 17







Φ5x6x14mm  
E x4

Step 18



## Step 19



## Step 20

