

REGENCY

Legacy Return Shell • LRT4724 • INSTRUCTIONS

Organize your parts. You may need a rubber mallet.



Parts:

A: Return Top



Quantity: 1

B: Leg



Quantity: 1

C: Back Panel



Quantity: 1

Hardware:

D: 4-Hole Flat Bracket



Quantity: 1

E: Corner Bracket



Quantity: 1

F: 2-Hole Flat Bracket



Quantity: 1

G: Thumb Screws



Quantity: 10

IMPORTANT NOTICE:

Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid scratching the parts. Check to be sure that you have all parts and hardware. Remove all wrapping materials, including staples & packing straps before you start to assemble. Keep all hardware parts and packaging out of reach of children.



Any problems or questions call Regency Office Furniture at 1-866-816-9822

REGENCY


Legacy Return Shell • LRT4724 • INSTRUCTIONS

Organize your parts. You may need a rubber mallet.

STEP 1: Attach **Back Panel (C)** to the underside of the **Return Top (A)** by lining up the Eclip with its corresponding holes, and sliding into place (see figure 1).




STEP 2: Attach **Leg (B)** to the underside of the **Return Top (A)** by lining up the Eclip with its corresponding holes, and sliding into place. While sliding over, line up Pins with corresponding holes in **Back Panel (C)** and press into place.



SPECIAL NOTE: Return is reversible. In Step 2, attach **Leg (B)** on left side of **Return Top (A)** for Right Return. Or, attach on right side of **Return Top (A)** for Left Return.

STEP 3: Using two people, flip over your assembled Return, and line it up with your assembled Desk Shell.




Note: Right Return shown.

REGENCY


Legacy Return Shell • LRT4724 • INSTRUCTIONS

Organize your parts. You may need a rubber mallet.

STEP 4: Attach **Corner Bracket (E)** to the underside of your desk, where the **Return Top (A)** and **Back Panel (C)** meet your Desk Top and Desk Leg. Attach by placing 4 **Thumb Screws (G)** through the **Corner Bracket (E)** and into the predrilled holes.



STEP 5: Place **4-Hole Flat Bracket (D)** to the underside of where **Return Top (A)** meets the Desk Top. Attach **4-Hole Flat Bracket (D)** by inserting 4 **Thumb Screws (G)** through the **4-Hole Flat Bracket (D)** and into the predrilled holes.



STEP 6: Under the desk, where the **Back Panel (C)** meets your Desk Leg. Attach **2-Hole Flat Bracket (F)** using 2 **Thumb Screws (G)**. Insert **Thumb Screws (G)** through the **2-Hole Flat Bracket (F)** and into the predrilled holes.



Note: Right Return shown.