




12'x20' Metal Patio Gazebo

ASSEMBLY MANUAL



MODEL#: LGMF1499C

Missing part? Damaged? Contact us via email at

service@domioutdoorliving.com

www.domioutdoorliving.com

Pre-assembly



1. Two or more people are required for assembly.



2. You will need one or more stepladders.



3. Wearing protective gloves is recommended.



4. You may need a safety hat.



5. Please use a Phillips screw driver.



6. For ease of construction, you may need a drill.



7. You may need a safety goggle.



8. Do not fully tighten screws prior to complete assembly.

Warning & Attention

-Try to assemble this product on the flat ground, otherwise it is difficult to carry out;

-It would be much easier to assemble the product with three or more people;


-After assembly, please check whether all screws are tightened, to prevent parts from falling apart.

▲ Use bolts to secure the frame to the ground to against the strong wind.



IMPORTANT: A gaze may entail to purchase a municipal permit or be subject to specific building codes. It is the consumer's responsibility to inform themselves of any restrictions.

MOUNTING BLUEPRINT

Gazebo 12x20





1




×20

If the deck is hard wood and the depth of it is over 3 inch, you can use **5/16 in. ×4 in. Structural Wood Screw** to mount the gazebo.



2




If the ground is concreted and the depth of it is over 3 inches you can use 1/4 inch expansion bolts to mount the gazebo




3


























Or you can make a concrete footing for gazebo, **15×15×15 inches** is recommended. use expansion bolts to mount the gazebo like ② shows.

IMPORTANT:
Anchor is not recommended








 Pole A (x4)			 Pole B (x2)		
 Beam C (x4)			 Track C1 (x4)		
 Gap Cover C2 (x2)			 Gap Cover C3 (x2)		
 Beam D (x4)			 Track D1 (x4)		
 Gap Cover D2 (x2)			 Gap Cover D3 (x2)		
 Beam E (x2)			 Track E1a (x2)  Track E1b (x2)		
 Gap Cover E2a (x2)		 Gap Cover E2b (x2)	 Union Bar F (x6)		 Corner Cover G (x4)
 Joint Cover H (x6)	 Joint Cover H1 (x6)	 Silicone Sealant H2 (x1)	 Corner Solidifying Bar J1 (x4)		 Corner Solidifying Bar J2 (x4)
 Outside Roof Cover Connector K1 (x1)		 Outside Roof Cover K2 (x2)		 Solidifying Bar K3 (x1)	
 Inside Roof Cover K4 (x2)		 Inside Roof Cover K5 (x1)		 Inside Roof Cover Connector K6 (x2)	

 Solidifying Bar K7 (x4)		 Base L (x4)	 Base L1 (x2)
 Corner Roof Tube Connector M (x4)		 Corner Roof Tube M1 (x4)	
 Middle Roof Tube N (x2)		 Middle Roof Tube N1 (x4)	
 Middle Roof Tube N2 (x2)		 Finishing Bar P (x2)	
 Small Mesh P1 (x1)		 Finishing Bar Q1 (x2)	
 Finishing Bar Q2 (x2)		 Plastic Bar Q3 (x2)	
 Plastic Bar Q4 (x4)		 Finishing End R (x8)	 Hook R1 (x3)
 Finishing End R2 (x2)	 Black Rubber S (x160)	 Finishing End T (x2)	
 Finishing End T1 (x2)		 Finishing End T2 (x2)	
 Solidifying Bar U1 (x4)		 Solidifying Bar U2 (x4)	
 Bracket U3 (x4)	 Bracket U4 (x8)	 Solidifying Bar U5 (x4)	


510		510		346		510		510		510		338	
257		827		1397		1555		1555		1388		818	
248		396		966		1536		1555		1555		1555	
1555		1555		1555		1527		958		388			
Mosquito Netting		Mosquito Netting		Strap		Solid Sidewall		Solid Sidewall					
Plastic Clips Z (x72)		Plastic Clips Z1 (x6)		Plastic Clips Z2 (x6)		Plastic Clips Z3 (x2)		Plastic Clips Z4 (x2)					
M6x16										1#			
M6x20										x308			
										2#			
										x36			
										3#			
										x16			
										4#			
										x152			
										5#			
										x100			
										6#			
										x8			
										7#			
										x48			
										8#			
										x6			
										9#			
										x28			
										10#			
										x4			
										11#			
										x36			
										12#			
										x20			
x1		x1		x1									





Assemble the Poles:
Attach Base #L to
Pole #A with 3 Bolts #1.







X4




Attach Base #L1 to Pole #B with 4 Bolts #1.








- (1) Insert Union Bar #F into Beam #D, and secure with 2 Bolts #1.
 - (2) Insert the other side of Union Bar #F into Beam #C and secure with 2 Bolts #1.
- Repeat the above procedures to assemble the other Beam #D and #C.









TIPS: It's a normal situation that there's a gap between the 2 beams, please use silicone sealant (part #H2) and Joint Cover #H to affix the gap.(see P11)



SECTION VIEW




- (1) Use 6 Bolts #1 to secure the Gap Cover #D2 to the Beam #D as shown;
- (2) Use 5 Bolts #1 to secure the Track #D1 to the Beam #D as shown;
- (3) Use 6 Bolts #1 to secure the Gap Cover #C2 to the Beam #C;
- (4) Use 5 Bolts #1 to secure the Track #C1 to the Beam #C.





(1) Insert Union Bar #F into Beam #E, and secure with 2 Bolts #1.

(2) Insert the other side of Union Bar #F into Beam #D and secure with 2 Bolts #1.


Repeat the above procedures to assemble the other Beam #E and #D.



TIPS: It's a normal situation that there's a gap between the 2 beams, please use silicone sealant (part #H2) and Joint Cover #H to affix the gap.(see P11)




SECTION VIEW



- (1) Use 6 Bolts #1 to secure the Gap Cover #D3 to the Beam #D as shown;
- (2) Use 5 Bolts #1 to secure the Track #D1 to the Beam #D as shown;
- (3) Use 5 Bolts #1 to secure the Gap Cover #E2a to the Beam #E as shown;
- (4) Use 4 Bolts #1 to secure the Track #E1a to the Beam #E as shown;
- (5) Use 5 Bolts #1 to secure the Gap Cover #E2b to the Beam #E as shown;
- (6) Use 4 Bolts #1 to secure the Track #E1b to the Beam #E as shown;
- (7) Use 6 Bolts #1 to secure the Gap Cover #C3 to the Beam #C as shown;
- (8) Use 5 Bolts #1 to secure the Track #C1 to the Beam #C as shown.




2#
x16




3#
x16


FRAME ASSEMBLY:



INSIDE VIEW




Please don't tighten
all bolts.




OUTSIDE VIEW



2#
x12



Please don't tighten
all bolts.




INSIDE VIEW

J1 (x4)


J2 (x4)

1#
x32



INSIDE VIEW



CORNER SOLIDIFYING
BAR ASSEMBLY:





9#
x16

Corner Cover & Joint Cover Assembly:






H (x6)







9#
x12



H2 (x1)

Use 5mm silicone sealant(part #H2) and Joint Cover #H to affix the gap.





4#
x56








H1 (x2)





8#
x2

(1) Slide the plastic hooks to the double-rail track #D1 & C1 (each slot should slide 7 plastic hooks).


Use Bolt #8 to secure the Joint Cover #H & H1 to the beam.









K4 (x2)



K5 (x1)




K6 (x2)




K7 (x4)


INSIDE ROOF COVER ASSEMBLY:



TOP VIEW




BOTTOM VIEW




1#
x24

- (1) Use 16 Bolts #1 to connect 4 Solidifying Bar #K7 with 2 Part #K4 & 1 Part #K5.
- (2) Use 8 Bolts #1 to connect 2 Inside Roof Cover Connector #K6 with 4 Solidifying Bar #K7.




BOTTOM VIEW




11#
x8

The 2 Part #K4 and 1 Part #K5 are connected by 2 Part #K6, then secure with 8 Bolts 11# and nuts.



M (x4)

M1 (x4)



2#
x8

CORNER ROOF TUBE ASSEMBLY:

Connect Part # M1 and Part #M with 2 Bolts #2 to form the Corner Roof Tube #M2.
Repeat the above procedures to assemble the other 3 Corner Roof Tubes.





X4

M2


CORNER ROOF TUBE AND INSIDE ROOF CONNECTOR ASSEMBLY:


Please have a freestanding ladder ready at the center of the gazebo.






Place 4 Part #M2 on the 4 corners of Inside Roof Cover,
Secure with 8 Bolts #1 (from bottom to top).






Place 4 Corner Roof
Tubes on the Poles,
Secure with 4 Bolts #1.







INSIDE VIEW



1#
x24


N x2
N1 x4
N2 x2

OUTSIDE VIEW




INSIDE VIEW


MIDDLE ROOF TUBE ASSEMBLY:




Check the the frame as pictures below shows.




Frames in Parallelogram shape



Frames in rectangular shape




K2 (x2)



K1 (x1)





K3 (x1)




1#
x6


OUTSIDE ROOF COVER ASSEMBLY


(1) Align the two Parts #K2 as shown, then place the Solidifying Tube #K3 on the bottom, secure with 6 Bolts 1# (from top to bottom).






(2)Put the Cover #K1 on the top of Parts #K2 and secure with 16 Bolts 11# and nuts(from top to bottom) to form a whole outside roof cover.








P1 (x1)





PLASTIC BAR ASSEMBLY:




Please pay attention to the hole position of the plastic tube #Q4 when insert them to the small mesh.







OUTSIDE ROOF COVER AND MESH ASSEMBLY


- (1) Place the Outside Roof Cover on the inside Roof Cover.
- (2) Align the holes and use 2 bolts #1 and 3 Hooks #R1 to secure the small mesh #P1 to the inside Roof Cover (From Bottom to Top).




Tighten the Hooks.




One Hook weight capacity: 15lbs.



Install the small mesh and finishing bar to the roof tube.




Please do not pull plastic bar out when installing it with #P, Q1& Q2on the middle roof tube.




12#
x8

11#
x4




BOTTOM VIEW




1





2




Plastic Bar
in the mesh









11#
x8






 Please install Plastic Clips in strict accordance with the instructions.




Attach Part #Z,#Z1,#Z2,#Z3&#Z4 by lightly tapping with screwdriver.



Small Roof Panel and Finishing Bar Assembly:



If you can't install #V, push the Outside Roof Cover up and try to insert them again.









R (x4)





R2 (x2)




12#
x12







Make sure the correct installation position of 2 part #U5









INSIDE VIEW





Solidifying Bar Assembly:







Attach Part #Z by lightly tapping with screwdriver.




X5




X6




X7




X8




X3



X4




X9




X10




X1



X2




X11









X12

Please install Clips #Z, Z1, Z2 in strict accordance with the instructions.





Install the Middle Panels (#X6, X7 or #W4,W5) first, then the small panels on the edge.






The Black Rubber #S should be assembled when installing the roof panels; please see the next page.




The Black Rubber #S should be inserted between roof panels and solidifying bars or beams, then secure with bolts and nuts.









Solidifying Bar


Middle Roof Tube








S x48

7#
x48



Solidifying Bar













④

Beam


5#





5#





MOSQUITO NETTING AND SOLID SIDEWALL ASSEMBLY:





Please close your gazebo curtain when it is incoming over 30 mph wind, and tie with Strap #Yb.



Thanks for your purchase.

At domi outdoor living, we believe in our products.

That's why we provide a 12-month warranty and friendly, easy-to-reach after-sales service. So, if you have any questions about our product or assembly, please feel free to contact us. We are here for you.

Support:



After-sales contact email:

service@domioutdoorliving.com

Business cooperation contact email:

marketing@domioutdoorliving.com

Please have your order ID available if you reach out for support.

If you have damaged parts or product, please send us photos for an immediate response.