

## Y-serise Installation Instruction




Left Hand Install



Right Hand Install




## Detailed Diagram



#### PART LIST


#### Check all parts according to the list before assembly



#### Recommended Tools

1/4"Drill Bit

Safety Gloves




\* Utilize Safety Glasses and Safety Gloves when constructing this shower door

Tape Measure

\* We recommend that 2 people work together to complete this installation


#### Left Hand Assembly

## 1. The adjustment range of Width 60 inches is shown in the following figure



#### Right Hand Assembly


1. The adjustment range of Width 60 inches is shown in the following figure



#### Instructions:

The width of this product can be expanded by up to 25mm(1 inch).


Minimum 127mm(5 inches) reduction As shown in the following picture



#### Instructions:


The width of this product can be expanded by up to 25mm(1 inch).

Minimum 127mm(5 inches) reduction As shown in the following picture




#### Left Hand Assembly

## 1. The adjustment range of Width 54 inches is shown in the following figure



#### Right Hand Assembly


1. The adjustment range of Width 54 inches is shown in the following figure



#### Instructions:

The width of this product can be expanded by up to 25mm(1 inch).


Minimum 127mm(5 inches) reduction As shown in the following picture



#### Instructions:


The width of this product can be expanded by up to 25mm(1 inch).

Minimum 127mm(5 inches) reduction As shown in the following picture




#### Left Hand Assembly

## 1. The adjustment range of Width 48 inches is shown in the following figure



#### Right Hand Assembly


## 1. The adjustment range of Width 48 inches is shown in the following figure



#### Instructions:

The width of this product can be expanded by up to 25mm(1 inch).


Minimum 127mm(5 inches) reduction As shown in the following picture




#### Instructions:


The width of this product can be expanded by up to 25mm(1 inch).


Minimum 127mm(5 inches) reduction As shown in the following picture





#### Left Hand Assembly




























#### Right Hand Assembly























#### STEP 1

#### Measure the finished opening width.




Before beginning installation, verify the door assembly will fit within the horizontal opening of the shower enclosure.


Measure distance "W1" of upper shower enclosure opening and distance "W2" of lower shower enclosure opening.


Both measurements should be within the dimensions listed above for required opening widths.


W1 = Upper Enclosure Width

W2 = Lower Enclosure Width












## Left Hand Assembly STEP 2

- 1. Disassemble the roller assembly 6 as shown, unscrew the cover and loosen the big bolt.
- 2. Reassemble the two pulley components onto the sliding door as shown in the picture. When finished, move the active panel to the shower area.








## Right Hand Assembly STEP 2

- 1. Disassemble the roller assembly 6 as shown, unscrew the cover and loosen the big bolt.
- 2. Reassemble the two pulley components onto the sliding door as shown in the picture. When finished, move the active panel to the shower area.





A

Move the active panel to the shower area.

I av the glass on a soft

Lay the glass on a soft padded surface!






## Left Hand Assembly STEP 3-1

- 1. Lean the template 22 on the wall.
- 2. Make sure to level the template.
- 3. Use pencil to mark the hole on the template.

# The hole at the edge of the glass door is not to be drilled Drill this hole on the edge of the fixed glass.









# Right Hand Assembly STEP 3-1

- 1. Lean the template 22 on the wall.
- 2. Make sure to level the template.
- 3. Use pencil to mark the hole on the template.












## Left Hand Assembly STEP 3-2

- 1. Drill a hole on the wall.
- 2. Hammer the Anchor into the hole.
- 3. Secure Wall Connector 3 onto the wall.








# Right Hand Assembly STEP 3-2


- 1. Drill a hole on the wall.
- 2. Hammer the Anchor into the hole.
- 3. Secure Wall Connector (3) onto the wall.



#### Left Hand Assembly

#### STEP 4-1


- 1.Insert the Rail Wall Connector 3 into the two sides of pull rod.
- 2.Utilize the 2.5mm Allen wrench to tighten the screw inside.



#### Right Hand Assembly


#### **STEP 4-1**


- 1.Insert the Rail Wall Connector 3 into the two sides of pull rod.
- 2.Utilize the 2.5mm Allen wrench to tighten the screw inside.



## Left Hand Assembly STEP 4-2


- 1. Screwing the rod and Wall Connector(3-B) in the Wall Connector(3-A).
- 2. Tightening by 2.5mm Allen Wrench.






# Right Hand Assembly STEP 4-2

- 1.Screwing the rod and Wall Connector(3-B)in the Wall Connector(3-A).
- 2. Tightening by 2.5mm Allen Wrench.








#### Left Hand Assembly


#### STEP 5

- 1. Install waterproof strips 23 on fixed glass near the wall.
- 2. Install waterproof strips 19 on the bottom of fixed glass.
- 3. Install wall connecting clip 24 on the wall.












## Right Hand Assembly


#### STEP 5

- 1. Install waterproof strips 23 on fixed glass near the wall.
- 2. Install waterproof strips 19 on the bottom of fixed glass.
- 3. Install wall connecting clip 24 on the wall.












#### Left Hand Assembly

#### STEP 6-1

- 1. Connect the fixed glass and rod.
- 2. Use a level to measure the fixed glass vertically.
- 3. Lock the wall clamp, tighten it with a 4cm allen wrench.








#### Right Hand Assembly

#### STEP 6-1


- 1. Connect the fixed glass and rod.
- 2. Use a level to measure the fixed glass vertically.
- 3. Lock the wall clamp, tighten it with a 4cm allen wrench.





#### Left Hand Assembly

#### STEP 6-2

1. Lock the rod, tighten it with a 2.5cm allen wrench.










#### Right Hand Assembly

#### STEP 6-2

1. Lock the rod, tighten it with a 2.5cm allen wrench.








#### Left Hand Assembly

#### **STEP 7-1**


- 1.Insert the Sliding Block 16 on the bottom of fix panel corner.
- 2.Mark the holes with pencil.
- 3. Put away the Sliding Block 16, drill the holes with a drill in the marks.
- 4.Insert the wall anchor.




#### Right Hand Assembly


#### **STEP 7-1**

- 1.Insert the Sliding Block 16 on the bottom of fix panel corner.
- 2.Mark the holes with pencil.
- 3. Put away the Sliding Block 16, drill the holes with a drill in the marks.
- 4.Insert the wall anchor.





#### Left Hand Assembly STEP 7-2 Install the Bottom Rail Connecting Part.





#### Right Hand Assembly STEP 7-2 Install the Bottom Rail Connecting Part.








#### Left Hand Assembly

#### STEP 7-3

- 1.Insert one end of the Base bar (15) into the bayonet of Sliding block (16).
- 2.Insert the other end into the Bottom Rail Wall Connecting Part 14,use 4\*25 Self-tapping,fixed to the wall with wall decoration cover 13.










#### Right Hand Assembly

#### STEP 7-3

- 1.Insert one end of the Base bar (15) into the bayonet of Sliding block (16).
- 2.Insert the other end into the Bottom Rail Wall Connecting Part 14,use 4\*25
  Self-tapping,fixed to the wall with wall decoration cover 13.








#### Left Hand Assembly

#### STEP 8-1


- 1. Hang the active panel on the top rail.
- 2.Make sure the bottom of the active panel loaded into the sliding block 16.



#### Right Hand Assembly

#### STEP 8-1


- 1. Hang the active panel on the top rail.
- 2.Make sure the bottom of the active panel loaded into the sliding block 16.




#### Left Hand Assembly

#### STEP 8-2

- 1.Use 2.5mm Allen wrench to rotate the eccentric shaft of the roller, adjust the height of the active panel.
- 2.Use 5mm Allen wrench to tight the roller.






#### Right Hand Assembly

#### **STEP 8-2**

- 1.Use 2.5mm Allen wrench to rotate the eccentric shaft of the roller, adjust the height of the active panel.
- 2.Use 5mm Allen wrench to tight the roller.





2.5mm
Adjustment Bushing
5mm

#### Left Hand Assembly

#### STEP 8-3

- 1.Install the Anti-Jumper 8 outside the active panel.
- 2.Use 2.5mm Allen wrench to tight inside.







### Right Hand Assembly

#### STEP 8-3


- 1.Install the Anti-Jumper 8 outside the active panel.
- 2.Use 2.5mm Allen wrench to tight inside.







# Left Hand Assembly STEP 9-1

Install the Bumper Strip 9 and Water-Retaining Gasket 11.










Top View
9
11

# Right Hand Assembly STEP 9-1

Install the Bumper Strip 9 and Water-Retaining Gasket 11.








Top View 3


9 - 9 - 9

11 - 9

# Left Hand Assembly STEP 9-2


- 1.Install the Handle (12).
- 2.Use 4mm Allen wrench to tight.
- 3. Apply glass glue for sealing






# Right Hand Assembly STEP 9-2


- 1.Install the Handle (12).
- 2.Use 4mm Allen wrench to tight.
- 3. Apply glass glue for sealing






#### Left Hand Assembly


1. Shower door can be enlarged by 25mm (1 inch).



2. Move the wall connecting part
3 and soft closing toward in a suitable position.




3. Tighten the screws of the wall connecting part 3 and soft closing.




3. Move the bottom rail wall connecting part forward.

#### Right Hand Assembly


1. Shower door can be enlarged by 25mm (1 inch).




2. Move the wall connecting part 3 and soft closing toward in a suitable position.



3. Tighten the screws of the wall connecting part 3 and soft closing.




3. Move the bottom rail wall connecting part forward.




#### Left Hand Assembly


1. Shower room can be reduced by 127mm (5 inches).




2. Move the soft closing towards the glass to the desired position.



3. Cut off the parts you don't need.





4. Cut off the unnecessary



#### Right Hand Assembly

1. Shower room can be reduced by 127mm (5 inches).






2. Move the soft closing towards the glass to the desired position.



3. Cut off the parts you don't need.



4. Cut off the unnecessary parts of the base bar.

