





# Butterfly Shower Door & Base

## SHOWER DOOR AND BASE INSTALLATION INSTRUCTIONS

### IMPORTANT

DreamLine® reserves the right to alter, modify or redesign products at any time without prior notice. For the latest up-to-date technical drawings, manuals, warranty information or additional details please refer to your model's web page on [DreamLine.com](http://DreamLine.com)



**STEP 1: Shower Base Installation Instructions**

**STEP 2: Shower Door Installation Instructions**



**Questions?**

Please Call **DreamLine** Customer Support: **1-855-831-2126**  
Hours of Operation M-F 8AM - 7PM EST and Saturday 9AM - 5PM EST

[Support@DreamLine.com](mailto:Support@DreamLine.com)



For more information about DreamLine® Shower Doors, Tub Doors & Enclosures, please visit [DreamLine.com](http://DreamLine.com)




# SLIMLINE SHOWER BASE

## SHOWER BASE DIMENSIONS AND INSTALLATION INSTRUCTIONS

### IMPORTANT!

DreamLine® reserves the right to alter, modify or redesign products at any time without prior notice. For the latest up-to-date technical drawings, manuals, warranty information or additional details please refer to your model's web page on [DreamLine.com](http://DreamLine.com)



Double Threshold Shower Base with Corner Drain Configuration  
shown as an example

### Color options:

- - White
- 22- Biscuit
- 88- Black

**Please review this entire manual before beginning installation**



### Questions?

Please Call **DreamLine Customer Support: 1-855-831-2126**  
Hours of Operation M-F 8AM - 7PM EST and Saturday 9AM - 5PM EST

[Support@DreamLine.com](mailto:Support@DreamLine.com)



For more information about DreamLine® products please visit [DreamLine.com](http://DreamLine.com)


## Preparation

1. Prior to installation, examine all boxes and packages for shipping damage and compare the piece count with your packing slip. After opening all boxes and packages read this introduction carefully. Check that all of the needed parts are included in the package by checking off the components on the "Detailed Diagram of Shower Door Components". If the unit has been damaged, has a finishing defect, or has missing parts, please contact our customer support department within **3 business days** of the delivery date. Please note that **DreamLine® will not replace any damaged products or missing parts free of charge after 3 business days or if the product has been installed.** Please contact DreamLine® if you have any questions and please provide an order number, job name or other proof of purchase to help identify the original order.
2. Install all of the required plumbing and drainage before installing the shower base. **Use a competent and licensed (if required by local code) plumber for all plumbing installation.**
3. **Shower bases must be installed by a licensed plumber. Please note that you should consult your local building codes with questions on installation compliance standards. Building and plumbing codes may vary by location and DreamLine® is not responsible for code compliance standards for your project.**
4. Make sure that prior to the installation the installation surface is leveled and solid and will be able to support the total weight of the unit. Also make sure the walls are at right angles. While some adjustment in leveling of the tray is possible, irregular installation surface level or improper angle of side walls will result in serious problems for your installation. Please note that some adjustments may be necessary during the installation process.
5. **Center drain configurations are centered on the width only. See technical drawing tables for drain locations.**
6. **Drain not included with this product.** The drain *opening* is 3-3/8" in diameter and **accepts a standard 2" compression fitted drain.**


### **IMPORTANT NOTE:**

**Dimensions provided are for reference only. Measure the actual shower tray before installation. This includes overall dimensions and drain location. Allowed tolerance for center of the drain is +/-1/2".**

## Tools Required



Tape  
Measure



Pencil



Level





Mortar





When constructing or installing a shower base, consider how **the thickness of the wall treatment (wallboard, tile, etc.) will affect the finished opening size for the shower door.**

Compare the overall dimensions of the shower door model with the finished opening size before proceeding with the installation.







When constructing or installing a shower base, consider how **the thickness of the wall treatment (wallboard, tile, etc.) will affect where the shower enclosure will sit on the threshold.** Compare the overall outside dimensions of the shower enclosure model size with the finished threshold before proceeding with the installation.



## SINGLE THRESHOLD SHOWER BASE



### Center Drain Configuration



MODEL	SPECIFICATION	D (in)	W (in)	D1 (in)	W1 (in)
DLT-1132320	32" x 32"	32"	32"	15"	16"
DLT-1136360	36" x 36"	36"	36"	15"	18"
DLT-1132420	32" x 42"	32"	42"	15"	21"
DLT-1134420	34" x 42"	34"	42"	15"	21"
DLT-1136420	36" x 42"	36"	42"	15"	21"
DLT-1142420	42" x 42"	42"	42"	20"	21"
DLT-1132480	32" x 48"	32"	48"	15"	24"
DLT-1134480	34" x 48"	34"	48"	15"	24"
DLT-1136480	36" x 48"	36"	48"	15"	24"
DLT-1132540	32" x 54"	32"	54"	15"	27"
DLT-1134540	34" x 54"	34"	54"	15"	27"
DLT-1136540	36" x 54"	36"	54"	15"	27"
DLT-1130600	30" x 60"	30"	60"	15"	30"
DLT-1132600	32" x 60"	32"	60"	15"	30"
DLT-1134600	34" x 60"	34"	60"	15"	30"
DLT-1136600	36" x 60"	36"	60"	15"	30"

## SINGLE THRESHOLD SHOWER BASE



### Left-Hand Drain Configuration



MODEL	SPECIFICATION	D (in)	W (in)	D1 (in)	W1 (in)
DLT-1130601	30"×60"	30"	60"	15"	12"
DLT-1132601	32"×60"	32"	60"	15"	12"
DLT-1134601	34"×60"	34"	60"	17"	12"
DLT-1136601	36"×60"	36"	60"	18"	12"



## SINGLE THRESHOLD SHOWER BASE

### Right-Hand Drain Configuration





MODEL	SPECIFICATION	D (in)	W (in)	D1 (in)	W1 (in)
DLT-1130602	30"×60"	30"	60"	15"	12"
DLT-1132602	32"×60"	32"	60"	15"	12"
DLT-1134602	34"×60"	34"	60"	17"	12"
DLT-1136602	36"×60"	36"	60"	18"	12"

## NEO ANGLE SHOWER BASE



MODEL	SPECIFICATION	W (in)	A (in)	B (in)	C (in)
DLT-2036360	36"×36"	36"	18 5/16"	25"	12"
DLT-2038380	38"×38"	38"	20 5/16"	25"	12"
DLT-2040400	40"×40"	40"	22 5/16"	25"	14 3/8"
DLT-2042420	42"×42"	42"	24 5/16"	25"	14 3/8"



## QUARTER ROUND SHOWER BASE



MODEL	SPECIFICATION	W (in)	C (in)	R (in)
DLT-7033330	33"×33"	33"	12"	21 5/8"
DLT-7036360	36"×36"	36"	12"	21 5/8"
DLT-7038380	38"×38"	38"	12"	21 5/8"

## DOUBLE THRESHOLD SHOWER BASE



### Corner Drain Configuration



MODEL	SPECIFICATION	W (in)	C (in)
DLT-1032320	32"×32"	32"	12"
DLT-1036360	36"×36"	36"	12"

## DOUBLE THRESHOLD SHOWER BASE



### Left-Hand Drain Configuration



MODEL	SPECIFICATION	D (in)	W (in)	D1 (in)	W1 (in)
DLT-1034481	34"×48"	34"	48"	17"	12"
DLT-1036481	36"×48"	36"	48"	18"	12"
DLT-1036541	36"×54"	36"	54"	18"	12"
DLT-1036601	36"×60"	36"	60"	18"	12"


## DOUBLE THRESHOLD SHOWER BASE

### Right-Hand Drain Configuration



MODEL	SPECIFICATION	D (in)	W (in)	D1 (in)	W1 (in)
DLT-1034482	34"×48"	34"	48"	17"	12"
DLT-1036482	36"×48"	36"	48"	18"	12"
DLT-1036542	36"×54"	36"	54"	18"	12"
DLT-1036602	36"×60"	36"	60"	18"	12"

## Shower Base Cross Section Diagram



## Shower Base Installation - Preparation

1. Ensure that the floor and the studs are at right angles.  
Provide a 5"×5" opening in the sub-floor for the drain.  
The 2" PVC waste pipe should extend above the surface of the sub-floor according to the drain installation instructions and the height of the Shower base.  
Refer to the product drawings and tables in this installation manual for the drain location.

See Fig. 1 and Fig. 2 for details.




Fig. 1




Fig. 2

2. Install the shower drain (**NOT INCLUDED**) according to the drain installation manual (supplied with the drain).

See Fig. 3 for example





Fig. 3

3. Place the tray into the designated position so that the Drain cutout drops around the Drain Pipe and butt the Shower Base up against the studs.

See Fig. 4 for details.



Lower the base over the drain pipe and set it into place against the studs.

Fig. 4

4. Level the tray and place marks on the studs above the upper edge of the tile flange.

See Fig. 5 for details.




Fig. 5

5. Mix the bedding material (Mortar, cement-sand mix, etc.) **Concrete or plaster is not recommended.** Apply enough bedding material to support the entire bottom of the shower base. This will add additional stability and prevent the base from shifting position.

See Fig. 6 for details.




Fig. 6

6. After the bedding material has been poured and *before* it sets, place the shower base into the position with the drain assembly sliding over the PVC waste pipe. It will be necessary to push the shower base until the top of the tile flange aligns with the marks drawn on the studs and the front edge is contacting the rough floor along the entire length of the shower base. Ensure that the base is level in all directions. You may need to use shims to hold the tray level until the bedding fully sets. Remove all excess mortar.




Fig. 7

7. Allow the bedding material to completely harden before applying weight to the bottom of the shower base.

Install the cement board (or the wallboard) above the tile flanges and secure it to the studs. Put the tiles (or other finishing wall material) over the cement board leaving 1/8" gap between the bottom of the tile or wall kit and the shower base. Use caulk to fill the gap.

See Fig. 8 and Fig. 9 for details.




Fig. 8




Fig. 9

## **Product Maintenance**

**BASES and BACKWALLS:** To ensure long lasting life for your acrylic base and/or back walls: wipe them off after each use with a soft cloth. To clean the acrylic base or back walls use non-abrasive sprays or cream based cleaners. Avoid the use of aerosol spray cleaners. Never use abrasive cleansers, metal brushes or scrapers that could scratch or dull the surface.

**GLASS:** To ensure long lasting life for your glass shower products: wipe them off after each use with a soft cloth. Rinse and wipe off the glass using either a soft cloth or a squeegee to prevent soap buildup and water spots (Hard water can etch the surface of the glass over time if left to dry). To prevent scratching the surface: never use abrasive cleaners or cleaning products that contain scouring agents. Never use bristle brushes or abrasive sponges that may scratch the surface.

**HARDWARE:** To ensure a long lasting finish: wipe off the metal parts after each use with a soft cloth. Do not use abrasive cleaners or cleaning products containing ammonia, bleach or acid. If accidentally used, rinse the surface as soon as possible to prevent damage to the finish (peeling or corrosion). After cleaning the polished finishes, rinse thoroughly and wipe dry with a soft cloth.

Clean stainless steel surfaces at least once a week. When applying stainless steel cleaner or polish to stainless steel hardware, work with (not across) the grain. Never use an abrasive sponge or cloth, steel wool or wired brush as these may permanently scratch the surfaces.

**NOTE:** To maximize the life of your door, it is important to regularly inspect the glass and other hardware for misalignment, proper attachment, and/or damage. Contact DreamLine with any questions or concerns.



TEL: [866-731-2244](tel:866-731-2244)

FAX: [866-857-3638](tel:866-857-3638)

[DREAMLINE.COM](http://DREAMLINE.COM)

For more information on [DreamLine® Shower Doors](http://DreamLine.com) and [Enclosures](#) please visit [DreamLine.com](http://DreamLine.com)




# BUTTERFLY

## SHOWER DOOR INSTALLATION INSTRUCTIONS

### IMPORTANT

DreamLine® reserves the right to alter, modify or redesign products at any time without prior notice for the purpose of product improvement and customer experience. Please refer to the model's web page on **DreamLine.com** for the latest technical drawings, installation manuals, warranty information or additional product details.



### MODEL #s

SHDR-4532726-01

SHDR-4536726-01

### Finish

01- Chrome

Left-Hinge installation shown

PLEASE REVIEW THIS ENTIRE MANUAL PRIOR TO INSTALLATION



### Questions?

Please Call **DreamLine Customer Support: 1-855-831-2126**  
Hours of Operation M-F 8AM - 7PM EST and Saturday 9AM - 5PM EST


[Support@DreamLine.com](mailto:Support@DreamLine.com)




For more information about DreamLine® Shower Doors, Tub Doors & Enclosures, please visit **DreamLine.com**



**NOTE:** This door is reversible for right or left-hinge door installation. The left-hinge door installation is shown as an example throughout this manual. For a right-hinge door installation, simply flip the entire door assembly over before positioning in the opening for installation. **(See step #6)**



Left-Hinge installation shown  
(door opens to the Left)



Right-Hinge installation shown  
(door opens to the Right)

## Table of Contents

Section title	Page #
Preparation	2
Tools	3
Detailed Diagram of Shower Door Components	4
Parts List	5
Installation Steps	6-14
Vinyl Seals/Handle	13
Product Maintenance	15



**NOTE:** This product should be installed by someone familiar with the construction requirements for this type of project and the care necessary for the safe installation and operation of the product.

# Preparation

1. Prior to installation, examine all boxes and packages for shipping damage and compare the piece count with the packing slip. After opening all boxes and packages read this introduction carefully. Check that all of the necessary parts are included in the package by checking off the components on the "Detailed Diagram of Shower Door Components". If the unit has been damaged, has a finishing defect, or has missing parts, please contact our customer support department within **3 business days** of the delivery date. **Please note that DreamLine® will not replace any damaged products or missing parts free of charge after 3 business days or if the product has been installed.** Contact DreamLine® if you have any questions, and please provide an order number, job name or other proof of purchase to help identify the original order.

2. **Please note that you should consult your local building codes with questions on installation compliance standards. Building and plumbing codes may vary by location, and DreamLine® is not responsible for code compliance standards for your project and will not accept any returns.**

3. If this unit is going to be installed in a new construction, please install all of the required plumbing and drainage before installing the shower. Use a competent and licensed (if required by local code) plumber for all plumbing installations.

4. Make sure that prior to beginning the installation, the surfaces are leveled and solid and will be able to support the total weight of the unit. Also make sure the walls are at right angles. Irregular installation surface level, radius corners or improper angle of side walls will result in serious problems for your installation. Note that some adjustments and drilling will be necessary during the installation process.

5. Protect all primary surfaces of the product during installation. Never set the glass down directly onto a tile floor. Leave corner protectors in place until necessary to remove them. Always use a piece of wood or cardboard to protect the bottom edge and corners of the glass prior to and during installation.

6. This unit must be installed upon a finished threshold and against finished walls.

7. This model has **3/4"** of adjustment for out-of-plumb wall conditions and/or overall width within the wall profiles. Confirm the finished opening dimensions and conditions before proceeding with the installation.

**NOTE:** Model **SHDR-4532726-##** is designed to fit a finished opening between 30"-31-1/2"  
Model **SHDR-4536726-##** is designed to fit a finished opening between 34"-35-1/2"

8. **Threshold must be level for proper installation.**

9. This model requires a minimum of **1"** of flat, level threshold space for installation.

10. **Professional installation recommended.**


11. **Two installers recommended.**




**NOTE: DO NOT** attach the handle/knob to the door glass until instructed.

**DO NOT** use the handle/knob to lift the glass during installation. This may result in damage to the glass and/or serious injury. Always use an assistant or a professional grade glass suction cup when handling heavy glass.

# Tools




Level



Tape Measure



Pencil



Carpenter's Square




Drill bit  
Ø5/16"  
(8mm)



Drill bit  
Ø1/8"  
(3mm)




Power Drill




Phillips  
Screwdriver



Hammer



100% Silicone




Work Gloves



Safety Glasses

Threshold must be level



**TIP:** Measure the finished opening before proceeding with the installation to be sure that the correct model size has been ordered.


**TIP:** Prior to installation, cover the shower/tub drain with tape to prevent losing screws or small parts.

**TIP:** Set screw gun clutch to low setting when installing screws and bolts to prevent stripping the heads.




**NOTE:** Unpack the product carefully and inspect it. Lay it out and identify all parts using the detailed diagram and parts list in this manual as a reference. Before discarding the carton, check for small hardware bags that may have fallen to the bottom of the box. If any parts are damaged or missing, please contact DreamLine® for replacement. The shipping boxes may contain extra parts not used in your model configuration.

**NOTE:** Retain these installation instructions for future reference.



# Detailed Diagram of Shower Door Components



All drawings in this manual are for illustrative purposes only and are not drawn to scale.

## Parts List

ITEM #	DESCRIPTION	QTY	ITEM #	DESCRIPTION	QTY
01	Wall Profile	2 pcs	10	Decorative Cover and Washer	4 pcs
02	Glass Profile	2 pcs	11	Center Hinge Assembly (top & bottom)	1 set
03	Guide Rail (top & bottom)	2 pcs	12	Roller Assembly (top & bottom)	1 set
04	Door Glass A	1 pc	13	Hinge Assembly (top & bottom)	1 set
05	Door Glass B	1 pc	14	Vinyl Seal Insert (pre-installed on part #2)	2 pcs
06	Ø5/16" Wall Anchor	8 pcs	15	Vertical Vinyl Seal	1 pc
07	ST4.2×10 Pan Head Screw	4 pcs	16	Roller Stopper	2 pcs
08	ST4.2×12 Truss Head Screw	6 pcs	17	Knob	1 set
09	ST4.2×40 Truss Head Screw	16 pcs	18	Allen Wrench	1 set

© DreamLine  
All Rights Reserved

# Installation steps




**NOTE:** Use caution when handling the door glass.  
Do Not bang the door glass together during assembly.



**1.** Carefully place **Door Glass A (#04)** and **Door Glass B (#05)** on a flat surface. **(Fig 1)**



**NOTE:** The distance from the long edge of the glass to the paired holes is different. Align the edges where the holes are closer as shown in **Fig 1**.





**Fig 1**



**Fig 2**


**2.** Attach the **Hinge Assemblies (top & bottom) (#13)** to the outside edge of the **Door Glass A (#04)** using the **Allen Wrench (#18)**. Install the **Hinge Assemblies (top & bottom) (#13)** onto the glass with the bolts facing toward the outside of the shower. Be sure that all gaskets are in place to prevent glass-to-metal contact. **(Fig 2)**

**3. Attach the Roller Assemblies (top and bottom) (#12) onto the correct holes on Door Glass B (#05) (this is the glass with the hole in the center for the knob). Install the Roller Assemblies (top and bottom) (#12) onto the glass with the bolts facing toward the outside of the shower. Be sure that all gaskets are in place to prevent glass-to-metal contact. (Fig 3)**




**Fig 3**

**4. Connect Door Glass A (#04) to Door Glass B (#05) using the Center Hinge Assemblies (top & Bottom) (#11). Install the Center Hinge Assemblies (top & Bottom) (#11) onto the glass with the bolts facing into the shower. Be sure that all gaskets are in place to prevent glass-to-metal contact. (Fig 4a and Fig 4b)**



**Fig 4a**



**Fig 4b**


**5. Attach the Guide Rails (top & bottom) (#03) to one of the Glass Profiles (#02) using the ST4.2×40 Truss Head Screws (#09). Start on the left end (as viewed from outside). (Fig 5)**




**NOTE:** Make sure the **Vinyl Seal Insert (#14)** on the **Glass Profile (#02)** is on the inside of the shower (**Fig 8a.1**).



**TIP:** Apply a small amount of liquid soap or wax to the threads of the screws to make installation easier and to prevent stripping the screw heads.




**Fig 5**



**Fig 6a**

**6. Slide Hinge Assembly (#13) side of the door glass assembly into the channel of the top and bottom Guide Rails (#03) from the right side, followed by the Roller Assemblies (#12). (Fig 6a and Fig 6b)**




**Fig 6b**



**NOTE:** This step will determine the handing of the door. Left-Hinge installation is shown. For a Right-Hinge installation, simply rotate the door assembly from top to bottom and insert the **Hinge Assembly (#13)** side into the left end of the guide rails first.


**7. Attach the Hinge Assemblies (#13) into the pre-drilled holes in the Guide Rails (top & bottom) (#03) using the ST4.2×12 Truss Head Screws (#08). (Fig 7)**




**Fig 7**

**8. Attach the remaining Glass Profile (#02) onto the right side of the Guide Rails (top & bottom) (#03) using the ST4.2×40 Truss Head Screws (#09).**

**(Fig 8a and 8b)**




**Fig 8a**




**Fig 8b**

**9.** Secure the **Roller Stoppers (#16)** to the top and the bottom **Guide Rails (#03)** into the pre-drilled holes using the **ST4.2x10 Pan Head Screws (#07)**. (**Fig 9**)




**Fig 9**

**10.** Slide the two **Wall Profiles (#01)** over both of the **Glass Profiles (#02)**. Be sure to position the **Wall Profiles (#01)** so that the flange with the predrilled holes faces inside the shower. (**Fig 10a and Fig 10b**)



**Fig 10a**




**Fig 10b**

**11.** Carefully position the assembled unit onto the threshold and slide the **Wall Profiles (#01)** outward, tight against the walls.

The **Wall Profiles (#01)** will allow for up to 3/4" of adjustment per side for out-of-plumb wall conditions or overall width adjustment within the model size.

Hold the assembled unit plumb and align it evenly across the threshold. **(Fig 11)**




**Fig 11**

**12.** From inside of the shower, mark the screw holes onto the wall through the pre-drilled holes in flanges of the **Wall Profiles (#01)**.

Move the entire assembly aside and drill  $\text{Ø}5/16''$  holes into the marks on the wall. Insert the **Wall Anchors (#06)** into the holes.

Place the assembled unit back onto the threshold and fasten the **Wall Profiles (#01)** to the walls using the **ST4.2×40 Truss Head Screw (#12)**. **(Fig 12)**




**Fig 12**

**13.** Perform any final adjustments with the **Wall Profiles (#01)** and make certain that the bottom rail is tight to the threshold. Drill  $\text{Ø}1/8''$  holes into the **Glass Profiles (#02)** through the **Wall Profiles (#01)**, approximately  $3/4''$  from the wall. Drill one hole approximately  $2''-4''$  from the top and bottom of each wall profile. Secure the **Wall Profiles (#01)** and the **Glass Profiles (#02)** together with the **ST4.2×10 Pan Head Screw (#07)** and the raised white **washers (#10)** and attach the **Decorative Covers (#10)**. (Fig 13)



**NOTE: Do Not** drill the profiles throughout, only through the first layer.




**Fig 13**

**14.** Test the operation of the **doors** and adjust the bolts on the **Rollers (#12)** if necessary to allow the doors to slide smoothly. (Fig 14)



**TIP:** Some additional minor adjustments to the rollers and hinges may be necessary so that the doors will close completely and seal tightly.




Start adjustments from the Hinge Side, then the Center Hinges and finally the Top and Bottom Roller assemblies.



**Fig 14**

**15.** Attach the **Knob (#17)** through the hole in **Door Glass B (#05)**.

Open the door and attach the **Vertical Vinyl Seal (#15)** to the vertical edge of the **Door Glass** that is on the shower head side so that the flange points away from the water flow. **(Fig 15)**



Attach the Vertical vinyl seal (#15) below the top hinge and above the bottom hinge

**Fig 15**

Left-Hinge installation shown


**16.** From the inside of the shower: Apply a good quality mildew-resistant silicone between the walls and the **Wall Profiles (#01)** and along the bottom **Guide Rail (#03)** and the threshold. **(Fig 16)**



**NOTE:** Surfaces must be clean and free of debris before applying silicone.



**TIP:** Allow 24 hours for the silicone to cure before using the shower.



**Fig 16**

## Product Maintenance

**BASES and BACKWALLS:** To ensure long-lasting life for your acrylic back walls, wipe them off after each use with a soft cloth. To clean the acrylic back walls use non-abrasive sprays or cream based cleaners. Avoid the use of aerosol spray cleaners. Never use abrasive cleansers, metal brushes or scrapers that could scratch or dull the surface.

**GLASS:** To ensure long-lasting life for your glass shower products, wipe them off after each use with a soft cloth. Rinse and wipe off the glass using either a soft cloth or a squeegee to prevent soap buildup and water spots (Hard water can etch the surface of the glass over time if left to dry). To prevent scratching the surface: never use abrasive cleaners or cleaning products that contain scouring agents. Never use bristle brushes or abrasive sponges that may scratch the surface.

**HARDWARE:** To ensure a long-lasting finish, wipe off the metal parts after each use with a soft cloth. Do not use abrasive cleaners or cleaning products containing ammonia, bleach or acid. If accidentally used, rinse the surface as soon as possible to prevent damage to the finish (peeling or corrosion). After cleaning the polished finishes, rinse thoroughly and wipe dry with a soft cloth. Clean stainless steel surfaces at least once a week. When applying stainless steel cleaner or polish to stainless steel hardware, work with (not across) the grain. Never use an abrasive sponge or cloth, steel wool or wired brush as these may permanently scratch the surfaces.

**NOTE: To maximize the life of your door, it is important to regularly inspect the glass and all hardware for misalignment, proper attachment, and/or damage. Contact DreamLine® with any questions or concerns.**

**DreamLine® shower doors and enclosures are designed not to leak when installed properly and the flow of water is not pointed directly at the vinyl seals.**

### **BUTTERFLY Shower Door Maintenance checklist**

- Inspect the **Hinge assemblies and Roller assemblies** and tighten if loose
- Inspect the **edges of the door glass** for damage
  - o **Damaged glass must be replaced!**
- Inspect all **vinyl seals**- replace if damaged or missing

© DreamLine  
All Rights Reserved



© DreamLine  
All Rights Reserved

TEL: 866-731-2244  
FAX: 866-857-3638  
DREAMLINE.COM

For more information on DreamLine® Shower Doors and Enclosures please visit **DreamLine.com**