




WAT30B

Water Dispenser



OWNERS MANUAL

Read and save these instructions.



A Name You Can Trust

Trust has to be earned and we will earn yours. Customer happiness is the focus of our business.

From the factory to the warehouse, from the sales floor to your home, the whole NewAir family promises to provide you with innovative products, exceptional service, and support when you need it the most.

Count on NewAir.

As a proud NewAir owner, welcome to our family. There are no robots here, real people shipped your product and real people are here to help you.

Thank you for your purchase and remember NewAir, A Name You Can Trust.

Call us today at 855-963-9247
Or email support@newair.com

For future reference, we recommend you attach a copy of your sales receipt here and record the following information. You will need this information if it becomes necessary to contact the manufacturer for service inquiries.

Date of Purchase: _____

Serial Number: _____

Model Number: _____



Connect with us online.

<http://www.NewAir.com>

READ AND SAVE THESE INSTRUCTIONS.

TABLE OF CONTENTS

Specifications	3
Safety Information & Warnings	4
Disposal Guidelines	5
Parts List.....	6
Installation & Setup	7
Cleaning & Maintenance.....	7
Troubleshooting.....	8
Limited Manufacturer's Warranty	10

SPECIFICATIONS

MODEL NO.	WAT30B
VOLTAGE:	115 V
FREQUENCY:	60 Hz
COOLING POWER:	100 W
HEATING POWER:	420 W
REFRIGERANT CODE NAME/QUANTITY:	R-134a/0.99oz

SAFETY INFORMATION & WARNINGS

To reduce the risk of fire, electrical shock and/or injury to persons or property please follow basic safety precautions. Be sure to read all instructions before using this appliance and observe the following safety tips:

ALWAYS DO THIS:

- ✓ Always transport your water dispenser in a vertical position and stand on a stable, level surface during use.
- ✓ Keep the water dispenser out of direct sunlight.
- ✓ Keep a distance of at least 6" (15 cm) from walls on all sides of the water dispenser.
- ✓ If the water dispenser is knocked over during use, turn off the unit and unplug it from the power supply immediately.
- ✓ Keep ventilation openings clear of obstruction.

NEVER DO THIS:

- Never use this appliance if it is not working properly, or if it has been dropped or damaged.
- Do not use hazardous chemicals to clean or allow them to come into contact with the unit. Do not use the unit in the presence of flammable substances or vapor such as alcohol, insecticides, gasoline, etc.
- Do not allow children to operate the unit unsupervised.
- Do not use liquids other than water in this unit.
- Do not plug in unit until water bottle is installed (see installation instructions below).
- Do not turn on the hot water setting without a water supply or the inside may catch fire.



Shock Hazard – Electrical Grounding Required



- This appliance is for indoor use only.
- Never attempt to repair or perform maintenance on the unit until the electricity has been disconnected.
- Never remove the round grounding prong from the plug and never use a two-prong grounding adaptor. Use of an extension cord is not recommended.
- Do not pull or place strain on the power cord when moving the appliance.

<http://www.NewAir.com>

- Altering or cutting of power cord, removal of power cord, removal of power plug, or direct wiring can cause serious injury, fire, or loss of property and/or life, and will void the warranty. If the power cord is damaged, it must be replaced by an electrician or specialized technician authorized by the manufacturer in order to prevent fire.
- Do not operate with an external switching device, such as a timer, or connect to a circuit that is regularly switched on and off by the utility.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Do not store explosive substances such as aerosol cans with flammable propellant in this appliance.
- Do not clean with a hose or highly pressurized water.
- WARNING---Do not damage the refrigerant circuit.
- WARNING---Do not use electrical appliances inside the food storage compartments of appliance, unless they are of the type recommended by the manufacturer.


DISPOSAL GUIDELINES

It is prohibited to dispose of this appliance in domestic household waste.

Disposing of waste in forests and landscapes endangers your health when hazardous substances leak into the ground-water and find their way into the food chain. For disposal, the following options may be available:

- The municipality may have established collection systems, where electronic waste can be disposed of free of charge to the user.
- When buying a new product the retailer may take back the old product free of charge.
- As old products contain valuable resources, they can be sold to scrap metal dealers.

PARTS LIST



No.	PART NAME	No.	PART NAME
1	button of hot water	10	tap of normal water
2	button of normal water	11	tap of hot water
3	button of cold water	12	water collector
4	bottle supporter	13	door
5	top cover	14	heating switch
6	power pilot lamp	15	cooling switch
7	heating pilot lamp	16	power supply cord
8	cooling pilot lamp	17	outlet of hot water
9	tap of cold water	18	condenser

NOTE:

This machine is suitable for bottle of 3 or 5 gallons. Don't use unhealthy hard water.

INSTALLATION & SETUP



Before connecting the appliance to a power source, let it stand upright for approximately 2 hours. This will reduce the possibility of a malfunction in the cooling system from handling during transportation.

LOCATION

- The water dispenser should be placed on a firm, even foundation to minimize noise and vibration.
- Do not place the dispenser in direct sunlight or near other heat producing appliances.
- To avoid accidental water damage, locate it away from furniture or other appliances.
- The unit must be placed within reach of a properly-rated grounded socket.
- Never place any obstacles around the air inlet or outlet of the unit.
- Allow a minimum 10 inch clearance on all sides for efficient operation.
- This unit should work in temperatures ranging from 50-109° Fahrenheit.

OPERATION

1. Remove the sticker or bottle cover from the bottle and place the bottle on top of the water dispenser. Do not plug the power cord in or turn on the heating switch until water runs from the hot water tap.
2. Insert the plug into an outlet and then turn on the switch. Indicators light up accordingly once the machine works.
3. Once the bottle is empty, remove and replace with a new bottle.

CLEANING & MAINTENANCE

Unplug the unit from the electric outlet before performing any maintenance or servicing the product.

CLEANING THE HOUSING

- Use a soft, damp cloth to wipe the body clean. Clean the drip tray and storage cabinet as needed.

A Name You Can Trust

- Remove dust from the condenser coils on the back of the unit to improve efficiency.
- Never use strong chemicals, gasoline, detergents, chemically-treated cloths, or any other cleaning solutions to clean the water dispenser, as these can all potentially damage the unit.
- Never use detergent or chemicals harmful to health when cleaning.
- Do not directly spray water on the surface of the product.

CLEANING AND DRAINING INSTRUCTION:

- ① Before cleaning, make sure the power switch in the O(off) position and unplug the water dispenser.
 - ② Vertically insert the bottle into the supporter on top of the machine.
 - ③ Open the taps, let about 1 liter water flow into a container.
 - ④ Remove the water bottle from the dispenser.
 - ⑤ Place a large bucket beneath the drain outlet. Remove the drain cover and allow water to drain.
 - ⑥ After draining, replace the drain cover and you can use the machine.
- Attention:** The dispenser heats water to a temperature of approximately 185 F/85 C. It can cause severe scalding. Please operate it carefully.

TROUBLESHOOTING

Problem	Possible Causes	Solution
There is no hot or cold water.	Overconsumption of hot or cold water in a short amount of time.	Wait until the unit is able to prepare more hot or cold water.
There is no water flow.	The water bottle may be empty.	Replace the water bottle.

Problem	Possible Causes	Solution
There is no water flow.	Bottle supporter inlet may be blocked by a bottle seal.	Remove the seal or cover and reinstall the bottle.
The bottle supporter is leaking.	The bottle may be broken.	Replace with a new bottle.
The unit is noisy.	The unit is not on a flat and level surface.	Place the machine on a flat and level surface.

LIMITED MANUFACTURER'S WARRANTY

This appliance is covered by a limited manufacturer's warranty. For one year from the original date of purchase, the manufacturer will repair or replace any parts of this appliance that prove to be defective in materials and workmanship, provided the appliance has been used under normal operating conditions as intended by the manufacturer.

Warranty Terms:

During the first year, any components of this appliance found to be defective due to materials or workmanship will be repaired or replaced, at the manufacturer's discretion, at no charge to the original purchaser. The purchaser will be responsible for any removal or transportation costs.

Warranty Exclusions:

The warranty will not apply if damage is caused by any of the following:

- Damage in transit or when moving the appliance
- Accident, alteration, misuse or abuse of the appliance such as using non-approved accessories.
- Use in commercial or industrial applications
- Fire, water damage, theft, war, riot, hostility or acts of God such as hurricanes, floods, etc.
- Use of force or damage caused by external influences
- Partially or completely dismantled appliances

Obtaining Service:

When making a warranty claim, please have the original bill of purchase with purchase date available. Once confirmed that your appliance is eligible for warranty service, all repairs will be performed by a NewAir™ authorized repair facility. The purchaser will be responsible for any removal or transportation costs. Replacement parts and/or units will be new, re-manufactured or refurbished and is subject to the manufacturer's discretion. For technical support and warranty service, please email support@newairusa.com

<http://www.NewAir.com>