


LHL-CST-003

2 Drawers Console Table




ASSEMBLY INSTRUCTION


ADULT ASSEMBLY REQUIRED

**THE PRODUCT MAY RECOMMENDED
ASSEMBLING BY MORE THAN ONE
PERSON.**

**PLEASE ASK FOR ASSISTANCE AT YOUR
CONVENIENCE BEFORE ASSEMBLING.**



Before You Start



Read through each step carefully and follow the proper order

Separate and count all your parts and hardware





Give yourself enough room for the assembly process

Have the following tools: Flat Head Screwdriver, #2 Phillips Head Screwdriver and Hammer


Caution: If using a power drill or power screwdriver for screwing, please be aware to slow down and stop when screw is tight. Failure to do so may result in stripping the screw.

Cam Lock Fastening System


This Cam Lock Fastening System will be used throughout the assembly process.



Parts Identification




Parts Identification




(A)

TOP




(B)

LEFT SIDE




(C)

MIDDLE PARTITION




(D)

RIGHT SIDE




(E)

MIDDLE




(F)

BACK




(G)

BOTTOM




(H)

UPPER METAL BRACE X2




(I)

LOWER METAL BRACE X2




(J)

SIDE METAL LEGS X2



(K)


BACK DRAWER X2




(L)

LEFT DRAWER X2


Parts Identification




RIGHT DRAWER X2



BACK DRAWER X2




BOTTOM SUPPORT BRACE X2




BOTTOM DRAWER X2

Hardware Identification




DOUBLE-HEADED SCREWDRIVER:
THIS TOOL ALLOWS YOU TO USE DIFFERENT HEAD FOR DIFFERENT
TYPE OF SCREWS BY SWITCH THE YELLOW HANDLE


Hardware Identification




BOLT
QTY: 8+1 spare




BOLT
QTY: 8+1 spare




SCREW
QTY: 16+1 spare




SCREW
QTY: 4+1 spare




BOLT
QTY: 4+1 spare




CAM LOCK
QTY: 12+1 spare




CAM BOLT
QTY: 12+1 spare




WOOD DOWEL
QTY: 8+1 spare




WOOD DOWEL
QTY: 6+1 spare




SCREW
QTY: 14+1 spare



HANDLE
QTY: 2




HEX KEY
QTY: 1




TIPPING RESTRAINT
HARDWARE KIT
QTY: 1




Step 1




Assemble screws
(part#1) vertically



Make sure screws are
lock up evenly on board




X 2




(7) x 12

Step 2




X 2



X 2




X 2




(8) x 8




Step 3






Step 4



Step 5




Step 6




Before attaching the back panel, be sure that the unit is at 90°
 Avant d'attacher le panneau arrière, assurez-vous que l'unité est à 90°
 Antes de fijar el panel posterior, asegúrese de que la unidad esté a 90°



Step 7




Step 8




Step 9




Step 10





Step 11




Step 12



Step 13








Step 14



Step15



PART LIST	FIGURE	QUANTITY	DESCRIPTION
14.1		2PC	LONG SCREW (Dia.4mmX38mmL)
14.2		2PC	SHORT SCREW (Dia.4mmX19mmL)
14.3		4PC	METAL "L"BRACKET
14.4		2PC	PLASTIC ANCHOR
14.5		2PC	CABLE




Follow the instructions printed on the plastic bag containing the tipping restraint hardware to attach the tip-over restraints to the unit and the wall.

NOTE: The tipping restraint hardware included is for drywall construction. It will be necessary to drill holes for the wall anchors. Depending upon your wall construction, different anchor hardware may be required. Please contact your local hardware store for assistance.

Maximum loads

This unit has been designed to support the maximum loads shown. Exceeding these load limits could cause sagging, instability, product collapse, and/or serious injury.



WARNING

Please make sure that all objects are removed before moving the assembled unit. The unit must be team lifted, not dragged or pushed. Failure to do so could cause instability, product collapse, and/or serious injury.