


ASSEMBLY INSTRUCTIONS

36INCH BATH VANITY (COMBO)





Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware.



Compare with the parts list to be sure all parts are present.

"DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED"

*** Use of power tool to assemble this product will invalidate any claim and damage this product making unsafe !!!**
*** Please assemble on a clean soft surface to avoid damage.**



Tools Required



IMPORTANT:

PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY

PLEASE DO NOT RETURN TO STORE



**Please do not return this product to the retailer!!
We are able to assist you in ANY way**

If you find that you have any trouble with assembly or missing or damaged parts please contact the seller.

Before Installation

Important – Please read these instructions fully before starting assembly

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.

- We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
- Please do not over tighten screws or bolts until the assembly is completed.
- Keep children and animal away from the work area, small parts could choke if swallowed.
- Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

Cam Lock Assembly Instructions





Diagram A



Insert Cam Bolt into hole as shown in diagram A.





Diagram B



Make sure not to insert the Cam Bolt:
Too deep as shown in figure B as this will cause
the Cam Lock to be misaligned and unable to
interlock properly.







Diagram C




Also avoid inserting the Cam Bolt too close to the
surface of the hole as shown in figure C, as this
will cause the Cam Lock to be too loose, and not
interlock properly.



Connect the panels together.




Insert the Cam Lock so the side opening fits over
the head of the Cam Bolt.



To tighten the Cam Lock, turn it clockwise on half
a turn with a flat screwdriver.















**Do not use an automatic screwdriver as it may
bend or break if too much power is imposed.*

Detail View - CABINET




Identifying the Hardware-Identify the hardware using the illustrations below.

Part List - N710P250654

1		2	
3		4	
5		6	
7		8	
9		10	
11		12	
13		14	


Part List - N710P250654

15




Bottom Drawer Panel - 4pcs

16





Right Drawer Face - 2pcs

17





Sink - 1pc

Hardware List - N710P250654

A  ø6x35mm	B  ø14.5x12mm	C  ø13x1/4"x38mm
Three in one bolts(18pcs)	Three in one lock(18pcs)	Hex-Head bolts(8pcs)
D  ø13x1/4"x28mm	E  ø1/4"x16x1mm	F 
Hex-Head bolts(2pcs)	Washer(10pcs)	Handle (8pcs)
G  ø5/32"x15mm	H  ø5/32"x28mm	I 
Handle screw (4pcs)	Handle screw (4pcs)	L-Bracket (2pcs)
J  ø7xø3.5x12mm	K  ø8x30mm	L  ø8xø4x25mm
Round head screw (4pcs)	Wood dowel(17pcs)	Round head screw(4pcs)
M  ø8xø4x32mm	N  4mm	O 
Round head screw(32pcs)	Allen key(1pc)	Anti fall hardware(1set)
P  ø6x30mm		
Wood dowel(16pcs)		

STEP: 1

A

8PCS



✓


Don't lean




Don't over tighten




STEP: 2

I		J		K	
2PCS		4PCS		2PCS	




STEP: 3




L	
4PCS	


STEP: 4

D		E		B		K	
2PCS		2PCS		8PCS		6PCS	





STEP: 5

C		E
3PCS		3PCS




STEP: 6

C		E
3PCS		3PCS




STEP: 7




C	2PCS	E	2PCS
---	------	---	------

STEP: 8





A	10PCS
---	-------

STEP: 9




B	K
	

10PCS **9PCS**





STEP: 10


M	F	G	H
16PCS	4PCS	2PCS	2PCS
		(Ø5/32" x 15mm)	(Ø5/32" x 28mm)

**X2****STEP: 11**


M	F	G	H
16PCS	4PCS	2PCS	2PCS
		(Ø5/32" x 15mm)	(Ø5/32" x 28mm)

**X2**

STEP: 12




STEP: 13




STEP: 14

Install the sink on the cabinet with glue.
Let stand for 24 hours




*Silicone glue is not included in the package to comply with safety regulations in certain shipping conditions.

STEP: 15




HINGE ADJUSTMENTS




① Sideways / Tilt adjustment

Turn the screw **clockwise** to move the door further away from the side of the cabinet
anticlockwise to move the door closer to the side of the cabinet




② ④ Height adjustment

While supporting the weight of the door, turn the screws
clockwise to move the door up
anticlockwise to move the door down




③ Forward and back adjustment

If the gap between the back of the door and the cabinet is too small, and the door may not close fully. Turn the screw
clockwise to decrease the gap between the door and the cabinet
anticlockwise to increase the gap between the door and the cabinet



ASSEMBLY INSTRUCTIONS

36 INCH CABINET






Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware.


Compare with the parts list to be sure all parts are present.

"DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED"

*** Use of power tool to assemble this product will invalidate any claim and damage this product making unsafe !!!**
*** Please assemble on a clean soft surface to avoid damage.**



Tools Required



(Not included)




(Not included)

IMPORTANT:

PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY

PLEASE DO NOT RETURN TO STORE



**Please do not return this product to the retailer!!
We are able to assist you in ANY way**

If you find that you have any trouble with assembly or missing or damaged parts please contact the seller.

Before Installation

Important – Please read these instructions fully before starting assembly

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.

- We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
- Please do not over tighten screws or bolts until the assembly is completed.
- Keep children and animal away from the work area, small parts could choke if swallowed.
- Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

Cam Lock Assembly Instructions





Diagram A



Insert Cam Bolt into hole as shown in diagram A.





Diagram B



Make sure not to insert the Cam Bolt:
Too deep as shown in figure B as this will cause
the Cam Lock to be misaligned and unable to
interlock properly.







Diagram C




Also avoid inserting the Cam Bolt too close to the
surface of the hole as shown in figure C, as this
will cause the Cam Lock to be too loose, and not
interlock properly.



Connect the panels together.




Insert the Cam Lock so the side opening fits over
the head of the Cam Bolt.



To tighten the Cam Lock, turn it clockwise on half
a turn with a flat screwdriver.











**Do not use an automatic screwdriver as it may
bend or break if too much power is imposed.*

Detail View - CABINET





Identifying the Hardware-Identify the hardware using the illustrations below.




Part List - WF323692

1		2	
3		4	
5		6	
7		8	
9		10	
11		12	
13			

Hardware List - WF323692


A  ø6x35mm Three in one bolts (37pcs)	B  ø14.5x12mm Three in one lock (37pcs)	C  ø10xø5x50mm Flat head screw (4pcs)
D  ø12x55mm Plastic stopper (4pcs)	E  Handle (1pc)	F  ø5/32"x20mm Handle screw (1pc)
G  Damping hinge (2pcs)	H  ø7xø3.5x15mm Flat head screw (12pcs)	I  Laminate pad(4pcs)
J  ø8x30mm Wood dowel (20pcs)	K  ø7xø3.5x15mm Round head screw(6pcs)	

STEP: 1




STEP: 2

B		J
4PCS		2PCS




STEP: 3


B		J
8PCS		4PCS




STEP: 4




STEP: 5



STEP: 6




STEP: 7






STEP: 8

	
2PCS	4PCS





STEP: 9



		
1PC	1PC	8PCS



STEP: 10




STEP: 11




Draw the spacing between the walls and the No.8, punch holes in the wall, and fix the No.8 to the wall with screws.

Note: Appropriate distance from the top of cabinet to the ground is 74.8".


STEP: 12



STEP: 13




HINGE ADJUSTMENTS




① Sideways / Tilt adjustment

Turn the screw
clockwise to move the door further away from
the side of the cabinet
anticlockwise to move the door closer to the
side of the cabinet



② ④ Height adjustment

While supporting the weight of the door, turn the
screws
clockwise to move the door up
anticlockwise to move the door down



③ Forward and back adjustment

If the gap between the back of the door and the
cabinet is too small, and the door may not close
fully. Turn the screw
clockwise to decrease the gap between the
door and the cabinet
anticlockwise to increase the gap between the
door and the cabinet

