


# PLASTIC GARDEN SHED PP8x8C

## Instructions for Assembly



### **WARNING**



Please read the instruction manual carefully before assembly.  
Please assembly strictly in accordance with the instruction.  
Please double-check to ensure that all parts of the package contents intact.  
To avoid injury, work gloves are recommended during assembly.

**SITE PREPARATION | PRÉPARATION DU SITE | PREPARACIÓN DEL LUGAR | VORBEREITUNG DES AUFSTELLUNGORTES | VOORBEREIDING VAN HET TERREIN | PREPARAZIONE DEL LUOGO DI ASSEMBLAGGIO | PREPARAÇÃO DO LOCAL**


**Level the ground surface | Nivelez la surface du sol | Nivele la superficie del suelo | Ebenen Sie die Bodenoberfläche | Maak de bodem vlak | Livellare la superficie del terreno | Nivele a superfície do solo**



**Recommendation: Construct a wooden or concrete base as a foundation | Recommandation: fabriquez une base en bois ou en béton en guise de fondation | Recomendación: construya una base de madera o de cemento a modo de cimiento | Empfehlung: Bauen Sie als Fundament eine Grundfläche aus Holz oder Beton | Aanbeveling: maak een houten of betonnen ondergrond als fundering | Raccomandazione: Costruire una base di legno o di cemento come fondamenta | Recomendação: Construa uma base de madeira ou de cimento como fundação**



**External floor measurements are: | Les mesures externes de la étage sont: | Las medidas del suelo externo son: | Die Außen-Bodenmaße betragen: | De afmetingen van de externe vloer zijn: | Le dimensioni esterne del pavimento sono: | As medidas externas do chão são:**



**BEFORE STARTING ASSEMBLY | AVANT DE COMMENCER LE MONTAGE | ANTES DE EMPEZAR EL ARMADO | VOR MONTAGEBEGINN | VOORDAT U BEGINT TE MONTEREN | PRIMA DI INIZIARE L'ASSEMBLAGGIO | ANTES DE INICIAR A MONTAGEM**

**Read the care and safety guidelines at the end of this manual | Check to ensure that there are no missing or damaged parts BEFORE starting or arranging assembly | Remove all parts from the package(s) and spread them out on a clean work surface | Review all assembly instructions | Assemble all the parts according to the directions in this manual. Do not skip any steps.**

Lisez les instructions de précaution et de sécurité à la fin de ce manuel | Assurez-vous qu'il n'y a pas de pièces manquantes ou endommagées AVANT de commencer ou d'organiser l'assemblage | Retirez toutes les pièces du/des paquet(s) et étalez-les sur une surface de travail propre | Lisez toutes les instructions de montage | Assemblez toutes les pièces selon les instructions de ce manuel. Ne sautez aucune étape.

**Lea las intrucciones de precauciones y seguridad que están al final de este manual | Asegúrese de que no faltan piezas ni están dañadas ANTES de comenzar o disponer el montaje | Saque todas las piezas del paquete o paquetes y póngalas sobre una superficie de trabajo limpia | Revise todas las instrucciones de montaje | Monte todas las piezas según las instrucciones de este manual. No se saltee ningún paso.**


Lesen Sie die Sicherheitsrichtlinien am Ende des Benutzerhandbuchs durch | Prüfen Sie bitte VOR dem Zusammenbau, dass keine Teile beschädigt sind oder fehlen | Nehmen Sie alle Teile aus der Verpackung und breiten Sie sie auf einer sauberen Arbeitsfläche aus | Gehen Sie noch einmal die komplette Aufbauanleitung durch | Bauen Sie alle Teile entsprechend der Anleitung in diesem Handbuch zusammen. Lassen Sie dabei keinen Arbeitsschritt aus.

**Lees de richtlijnen voor zorg en veiligheid achterin deze handleiding | Controleer dat er geen onderdelen mankeren, of beschadigd zijn, VOORDAT u met de montage begint | Haal alle onderdelen uit het pakket (of uit de pakketten) en leg ze opeen schoon werkoppervlak | Bekijk alle montagehandleidingen | Monteer alle onderdelen volgens de aanwijzingen van deze handleiding. Sla geen stappen over.**

Leggere le linee guida di assistenza e sicurezza alla fine di questo manuale | Assicurarsi che non ci siano parti mancanti o danneggiate PRIMA di iniziare l'assemblaggio | Estrarre tutti i componenti dall'imballo e posizionarli su una superficie di lavoro pulita | Consultare tutte le istruzioni di montaggio | Assemblare tutti i componenti secondo le istruzioni contenute nel manuale. Non saltare nessuna fase.


**Leia as diretrizes de cuidados e segurança que constam da parte final deste manual | Verifique para se assegurar de que não há peças em falta ou danificadas ANTES de começar a preparar a montagem | Retire todas as peças da embalagem e espalhe-as numa superfície de trabalho limpa | Reveja todas as instruções de montagem | Monte todas as peças de acordo com as instruções do manual. Não salte quaisquer passos.**

**REQUIRED TOOLS | OUTILS EXIGÉS | HERRAMIENTAS NECESARIAS | BENÖTIGTE WERKZEUGE | BENODIGD GEREEDSCHAP | ATTREZZATURA OCCORRENTE | FERRAMENTAS NECESSÁRIAS**



**SPATULA | SPATULE | ESPÁTULA | SPACHTEL | SPATEL | SPATOLA | ESPÁTULA**

- Use spatula (part "SG8") for easier insertion of panel into profile.
- Utilisez la spatule (partie "SG8") pour une meilleure insertion du panneau dans le profil.
- Utilice una espátula (pieza "SG8") para una mejor inserción del panel en el perfil.
- Benutzen Sie den Spachtel (Bezeichnung "SG8"), um die Platten leichter in die Nut einführen zu können.
- Gebruik spatel (onderdeel SG8) voor het gemakkelijk invoeren van het paneel in het profiel.
- Utilizzare la spatola (parte SG8) per inserire il pannello più facilmente nel profilo.
- Utilize uma espátula (peça "SG8") para facilitar a inserção do painel no perfil.



**SG8 x2**




**ASSEMBLY REQUIRES TWO PEOPLE | LE MONTAGE DOIT ÊTRE EFFECTUÉ PAR DEUX PERSONNES | SE NECESITAN DOS PERSONAS PARA ARMARLO | ZWEI PERSONEN ZUR MONTAGE NOTWENDIG | MONTAGE VEREIST TWEE PERSONEN | L'ASSEMBLAGGIO RICHIEDE DUE PERSONE | A MONTAGEM EXIGE DUAS PESSOAS**








## PARTS LIST

| NO.    | PART. | Qty. | NO.   | PART. | Qty. | NO.    | PART. | Qty. |
|--------|-------|------|-------|-------|------|--------|-------|------|
| QF2-1  |       | 9    | QP20  |       | 4    | QD2-6  |       | 1    |
| QF2-2  |       | 3    | QS4   |       | 2    | 1QA2L  |       | 1    |
| QP8    |       | 4    | PS5   |       | 2    | EA2R   |       | 1    |
| QP3    |       | 4    | SS6   |       | 2    | EA2L   |       | 1    |
| QP19   |       | 2    | SG14  |       | 4    | 1QA1   |       | 1    |
| QP18   |       | 2    | UW1-1 |       | 1    | DS1    |       | 2    |
| DP4    |       | 1    | DA3   |       | 1    | DA4    |       | 2    |
| SG6    |       | 4    | BJ-1  |       | 1    | SG20   |       | 2    |
| SG7-1  |       | 1    | 1QA1L |       | 1    | SG9    |       | 5    |
| SG7-2  |       | 1    | EA1R  |       | 1    | MO3-6L |       | 1    |
| SG19   |       | 3    | SG10  |       | 2    | MO3-7  |       | 1    |
| QW2-1  |       | 8    | SG101 |       | 2    | Drill  |       | 1    |
| QW5-1  |       | 6    | SG102 |       | 2    | MO4    |       | 1    |
| QW4-1  |       | 2    | QR2-1 |       | 8    | MO1    |       | 4    |
| QW2-3  |       | 4    | QR2-2 |       | 4    | DC     |       | 2    |
| QW5-2  |       | 3    | QP21  |       | 4    | Z425   |       | 4    |
| QW4-2  |       | 2    | QP4   |       | 4    | RF7    |       | 4    |
| QW4-3  |       | 2    | QAP2  |       | 4    | Z410   |       | 196  |
| QT1-6  |       | 2    | CS2-2 |       | 4    | Z420   |       | 159  |
| QT1-7  |       | 2    | CS4-1 |       | 2    | ZW413  |       | 89   |
| QT1-8  |       | 2    | 8-6   |       | 2    | SG8    |       | 2    |
| QT1-9  |       | 2    | 8-5   |       | 2    |        |       | 2    |
| QT1-10 |       | 2    | SG2   |       | 4    |        |       | 1    |
| BY     |       | 2    | SG1   |       | 2    |        |       |      |
| QAP7   |       | 2    | QD2-1 |       | 1    |        |       |      |
| QAP8   |       | 2    | QD2-2 |       | 1    |        |       |      |
| SS3    |       | 2    | QD2-3 |       | 1    |        |       |      |
| SS4    |       | 2    | QD2-4 |       | 1    |        |       |      |
| QAP1   |       | 4    | QD2-5 |       | 1    |        |       |      |





- Use spatula  (part "SG8" ) for easier insertion of panel into profile.
- Please ensure the panels are all installed on position before screwing.
- Please be mindful of the screw size used during installation; using screws that are too long may damage the shed.

# Floor Assembly






- When installing the floor, when the textured face up to have the floor installed in a flat state.




# 01

## 01-1




### QF2-1



3 PC

### QF2-2



1 PC

### QP3



2 PC

### QP19



1 PC

### QP18




1 PC

### SG6




2 PC




## 01-2



## 01-3




## 01-4









OK!

# 02


## 02-1




| QP8   | SG19  | Z410  | Z420  |
|---|---|---|---|
|  |  |  |  |
| 2 PC  | 1 PC  | 4 PC  | 14 PC   |




## 02-2






## 02-3



## 02-4



Screw along the marked lines in profile



## 03-1

QF2-2



1 PC

QF2-1



3 PC

QP19



1 PC

SG19



1 PC

Z410









4 PC


Z420



6 PC




## 03-2




$A=B$



The panel texture should be aligned





## 03-3






## 03-4




## 04-1





|   |
|---|
| <b>QP8</b>  |
|  |
| 2 PC  |
| <b>QF2-2</b>  |
|  |
| 1 PC  |
| <b>QF2-1</b>  |
|  |
| 3 PC  |

## 04-2




## 04-3




**A=B**

The panel texture should be aligned



# 05

## 05-1




Z410



8 PC

Z420



11 PC

QP3



2 PC

SG6




1 PC

SG19




1 PC

## 05-2










## 05-3




# 06

## 06-1


|  |   |   |   |   |  |
|--|---|---|---|---|--|
| <b>QP18</b><br><br>1 PC | <b>DP4</b><br><br>1 PC | <b>SG7-1</b><br><br>1 PC | <b>SG7-2</b><br><br>1 PC | <b>SG6</b><br><br>1 PC | <b>Z420</b><br><br>8 PC |
|--|---|---|---|---|--|



## 06-2




## 06-3








Z410



4 PC



## Wall Assembly



● Use spatula (part "SG8") for easier insertion of panel into profile.

● Please make sure the panels with right position before install as shown in the figure.


# 08

QP20




1 PC

QW2-1




4 PC

QW5-1




4 PC

QW2-3



2 PC

QW5-2



2 PC

QAP7




1 PC

QAP8




1 PC


## 08-1







## 08-2



## 08-3



## 08-4




# 09

QP20




1 PC

QW2-1




2 PC

QW5-1




2 PC

QW2-3



1 PC

QW5-2




1 PC

QAP8




1 PC


## 09-1












## 09-2



## 09-3



## 09-4



QAP7




1 PC

QP20




2 PC

QW2-1



2 PC

QW2-3



1 PC

QW4-3




2 PC

QW4-2




2 PC

QW4-1




2 PC


## 10-1







## 10-2




## 10-3



## 10-4




## 11-1




|              |  |      |
|--------------|--|------|
| <b>1QA1L</b> |  | 1 PC |
| <b>EA1R</b>  |  | 1 PC |
| <b>Z410</b>  |  | 2 PC |
| <b>DA3</b>   |  | 1 PC |
| <b>UW1-1</b> |  | 1 PC |




## 11-2





## 11-4




## 12-1





## 12-2



C=D




## 12-3 fixation after aligning




# 13

## 13-1

Attention to the location of the screws: they need to be locked on the iron pipe that corresponds to the inside of the plastic profile.



SS6



2 PC

Z410




8 PC


ZW413




12 PC





## 13-2




Attention to the location of the screws: they need to be locked on the iron pipe that corresponds to the inside of the plastic profile.




## 13-3




|                          |                           |                          |                          |                          |                       |                          |
|--------------------------|---------------------------|--------------------------|--------------------------|--------------------------|-----------------------|--------------------------|
| <b>QT1-9</b><br><br>2 PC | <b>QT1-10</b><br><br>2 PC | <b>QT1-8</b><br><br>2 PC | <b>QT1-6</b><br><br>2 PC | <b>Z410</b><br><br>28 PC | <b>BY</b><br><br>2 PC | <b>QT1-7</b><br><br>2 PC |
|--------------------------|---------------------------|--------------------------|--------------------------|--------------------------|-----------------------|--------------------------|




## A-1



## A-2







# A-3




# A-4

This is the inside.












|              |  |       |
|--------------|--|-------|
| <b>Z410</b>  |  | 8 PC  |
| <b>ZW413</b> |  | 14 PC |
| <b>PS5</b>   |  | 2 PC  |
| <b>SS3</b>   |  | 2 PC  |
| <b>SS4</b>   |  | 2 PC  |




Pay attention to the placement of SS4.



Attention to the location of the screws: they need to be locked on the iron pipe that corresponds to the inside of the plastic profile.

## 16-1




**8-5**



2 PC

**RF7**




4 PC

**Z410**





4 PC

## 16-2








**8-5**




**OK!**

# Foor Assembly




● Use spatula (part "SG8") for easier insertion of panel into profile.



## 17

### 17-1



**QR2-1**



8 PC

---




**QR2-2**

4 PC


### 17-2



## 18-1



## 18-2





## 18-3

Make sure the sheet and profiles are in place before nailing

### Z410




16 PC



## 19-1

Flip the panel.



QP21



4 PC

QP4




4 PC

SG2



4 PC

SG20



2 PC

Z410




8 PC

Z420




8 PC

## 19-2




## 19-3

A=B C=D




## 19-4



## 20-1

Flip the panel.





x2

Z420




28 PC

## 20-2







x2

## 20-3




SG8





Fully fit the panel inside the profile

## 21-1 Fully fit the panels inside the profiles of roof




SG8




outside



## 21-2 QAP2 and QAP8 should be aligned once the roof is installed.





## 21-3




Z420



20 PC




# 22



Attention : for the convenience of screwing, please press the board when you screw.

Attention to the location of the screws: they need to be locked on the iron pipe that corresponds to the inside of the plastic profile.





ZW413




4 PC

# 23





## A-1



CS2-2



4 PC







● Fold at Angle that fits QP21.

# x2





# A-2

Please fasten the nail in the order of the **B** → **C** → **D**

|   |   |   |
|---|---|---|
| <b>Z420</b>   | <b>ZW413</b>  | <b>Z410</b>   |
|  |  |  |
| 8 PC  | 8 PC  | 16 PC   |






**x2**






DRILL holes in advance and then into the Z420 fixed.

# A-3





|   |
|---|
| <b>CS4-1</b>  |
|  |
| 2 PC  |
| <b>ZW413</b>  |
|  |
| 8 PC  |





• Fold at Angle that fits CS2-2.


**x2**




## 24-1




## 24-2



Attention to the location of the screws: they need to be locked on the iron pipe that corresponds to the inside of the plastic profile.



### SG1



2 PC

### Z425



4 PC

### 8-6



2 PC

### Z410






6 PC

### ZW413





4 PC

## 24-3



## 25-1



**QS4**




2 PC



**ZW413**




8 PC



Attention to the location of the screws: they need to be locked on the iron pipe that corresponds to the inside of the plastic profile.



## 25-2




**SG14**





4 PC



**Z420**




4 PC




x4




## A-1



## A-2




## Window section




|              |  |       |
|--------------|--|-------|
| <b>SG10</b>  |  | 2 PC  |
| <b>SG101</b> |  | 2 PC  |
| <b>SG102</b> |  | 2 PC  |
| <b>Z410</b>  |  | 32 PC |

### A-1




### A-2


- Remove the film before fixing SG101








- Two persons are needed for this step, to press SG10 from outside and inside.



### A-3





# Door Assembly







## 28

### 28-1



- QD2-1**  
  
1 PC
- QD2-2**  
  
1 PC
- QD2-3**  
  
1 PC
- QD2-4**  
  
1 PC
- QD2-5**  
  
1 PC
- QD2-6**  
  
1 PC
- SG9**  
  
5 PC









### 28-2




## 29-1

LEFT DOOR

RIGHT DOOR




1QA2L




1 PC

EA2R



1 PC

EA2L



1 PC

1QA1



1 PC

DA4



2 PC

DS1











2 PC

## 29-2

LEFT DOOR

RIGHT DOOR




## 29-3

LEFT DOOR

RIGHT DOOR


LEFT DOOR

RIGHT DOOR



Flip the panel.

## 30-1




ZW413




Z410




MO1




## 30-2



## 30-3





## 30-4





Don't fasten the screws in this step to adjust the positions of doors


## 31-1





- Z410**  
 28 PC
- DC**  
 2 PC






Nail the door after place adjustment and fasten all the screws.



## 31-2



## 32-1




**Z410**




12 PC

**M03-6L**



1 PC

**M03-7**



1 PC

**M04**







1 PC

**ZW413**



2 PC

## 32-2




**OK!**



# PARTS SCHEMATIC

## ROOF PARTS



## Door Parts

