

SHARP®

Simply Better Living

works
with

alexa

SMD2489ES **SMART MICROWAVE DRAWER OVEN**

Alexa Command List

SMD2489ES ALEXA COMMAND LIST

With the Amazon Alexa App or an Echo device you can enjoy hands-free cooking with over 35 Alexa voice commands.

MENU ITEM	COMMAND	QUANTITY RANGE
Open	Alexa, open the microwave.	-
+ 30 Seconds	Alexa, add 30 seconds to the microwave.	100% Power
Add Time	Alexa, add X minutes to the microwave. Alexa, add Y seconds to the microwave.	X = 01:00 – 60:00 Y = 00:01 - 00:59
Pause Time	Alexa, pause the microwave.	-
Resume Time	Alexa, resume the microwave.	-
Stop Time	Alexa, stop the microwave.	-
Time Cook	Alexa, microwave/cook for X minutes and Y seconds. Alexa, reheat for X minutes and Y seconds.	X = 01:00 - 60:00 Y = 00:01 - 00:59
Time Cook (Time & Power Level)	Alexa, microwave/cook for X minutes at level Y.	X = 01:00 - 60:00 Y = 1 - 10
Time Defrost	Alexa, defrost for X minutes. Alexa, defrost for Y seconds.	X = 01:00 - 60:00 Y = 00:01 - 00:59
Popcorn	Alexa, microwave/cook popcorn. Alexa, microwave/cook X popcorn.	X = Regular / Mini
Reheat	Alexa, reheat leftovers. Alexa, reheat dinner plate.	-

SMD2489ES ALEXA COMMAND LIST CONT.

MENU ITEM	COMMAND	QUANTITY RANGE
Fish	Alexa, microwave/cook fish.	-
Fresh Vegetables	Alexa, microwave/cook fresh vegetables.	Quick Fresh / Longer Fresh Vegetables
Frozen Entrée	Alexa, microwave/cook frozen entrée.	-
Frozen Vegetables	Alexa, microwave/cook frozen vegetables.	-
Ground Meat	Alexa, microwave/cook ground meat.	-
Potatoes	Alexa, microwave/cook potatoes. Alexa, microwave/cook baked potatoes. Alexa, microwave/cook sweet potatoes.	Baked / Sweet Potatoes
Rice	Alexa, microwave/cook rice. Alexa, microwave/cook brown rice. Alexa, microwave/cook white rice.	Brown / White Rice
Seafood	Alexa, microwave/cook seafood.	-
Steamer Bags	Alexa, microwave/cook steamer bags.	-
Bone-In Poultry (Defrost)	Alexa, defrost bone-in poultry.	X = 0.5 - 3.0 lbs.
Boneless Poultry (Defrost)	Alexa, defrost boneless poultry.	X = 0.5 - 2.0 lbs.
Casserole (Defrost)	Alexa, defrost casserole. Alexa, defrost X cups of casserole.	X = 1 / 2 / 3 / 4 / 5 / 6 cups
Chops (Defrost)	Alexa, defrost chops. Alexa, defrost X pounds of chops.	X = 0.5 - 3.0 lbs.

SMD2489ES ALEXA COMMAND LIST CONT.

MENU ITEM	COMMAND	QUANTITY RANGE
Ground Meat (Defrost)	Alexa, defrost ground meat. Alexa, defrost X pounds of ground meat.	X = 0.5 - 2.0 lbs.
Roast (Defrost)	Alexa, defrost roast. Alexa, defrost X pounds of roast.	X = 0.5 - 4.0 lbs.
Steaks (Defrost)	Alexa, defrost steaks. Alexa, defrost X pounds of steaks.	X = 0.5 - 3.0 lbs.
Soup (Defrost)	Alexa, defrost soup. Alexa, defrost X cups of soup.	X = 1 / 2 / 3 / 4 / 5 / 6 cups
Beverage (Reheat)	Alexa, reheat beverage. Alexa, reheat X cups of beverage.	X = 0.5 / 1 / 1.5 / 2 cups
Hot Cereal	Alexa, microwave/cook hot cereal. Alexa, microwave/cook X cups of hot cereal.	X = 1 / 2 / 3 / 4 / 5 / 6 servings
Hot Water	Alexa, microwave/cook hot water. Alexa, microwave/cook X cups of hot water.	X = 1 / 2 / 3 / 4 / 5 / 6 cups
Butter (Melt)	Alexa, melt X tablespoons of butter.	X = 2 - 8 tbsp.
Chocolate (Melt)	Alexa, melt X oz. of chocolate.	X = 1 - 8 oz.
Cream Cheese (Soften)	Alexa, soften cream cheese. Alexa, soften X oz. of cream cheese.	X = 2 - 8 oz.

SMD2489ES ALEXA COMMAND LIST CONT.

MENU ITEM	COMMAND	QUANTITY RANGE
Ice Cream (Softening)	Alexa, soften ice cream. Alexa, soften X cups of ice cream.	X = 2 - 6 cups
Dessert Topping (Warm)	Alexa, warm dessert topping. Alexa, warm X cups of dessert topping.	X = 0.25 - 0.5 cups
Syrup (Warm)	Alexa, warm syrup. Alexa, warm X cups of syrup.	X = 0.25 - 0.5 cups

Amazon, Echo, Alexa, and all related logos are trademarks of Amazon.com, Inc. or its affiliates.

© 2021 Sharp Electronics Corporation. All rights reserved.

Sharp and all related trademarks are trademarks or registered trademarks of Sharp Corporation and/or its affiliated companies. All other trademarks are property of their respective owners.

QUESTIONS?

1.800.BE.SHARP

SIMPLY BETTER LIVING

At Sharp Home Electronics Company of America, we are committed to Simply Better Living. Our innovative home appliance products are SIMPLE to use, BETTER than the competition, and encourage a HEALTHY LIFESTYLE.

SHARP ELECTRONICS CORPORATION
100 Paragon Drive, Montvale NJ, 07645
1.800.237.4277 • www.sharppusa.com



SHARP
Be Original.