

Cautions:

1. Please abide by related country, regional and local law and regulations when installing this fixture.

- 2. Please turn off the power before installation or maintenance.
- 3. Proper grounding is required to ensure safety.

Notice:

1. To avoid possibility of electrical shock or fire, the installation personnel must have professional electrical knowledge.

2. Please wear gloves to avoid injury before installation.

3. If any smoke or spark of the wire happens, please turn off the power immediately and notify relevant personnel.

Attention:

1. Please check if there is any damage during shipping. If so, please contact manufacturer immediately.

2. Please read the installation instructions carefully to check whether all the accessories are complete. After confirmation, install the fixture according to installation steps.

Wiring Diagram & Instruction:

3 dimming functions are available in this high bay light:

- 1. Constant current can be achieved by
- 1-10VDC dimming;
- 2. PWM signal dimming;
- 3. Variation of resistance unit dimming.

Please choose the appropriate dimming function according to your needs. You can also choose not to use this function.





3 Installation Methods: Hook Mount, Ceiling Mount, M20 Mount

A. Hook Mount:

 Screw the lifting ring into the high bay light fixture, then tighten firmly. (Figure 1)
 Hang the fixture into the lifting hook and protect it from falling. (Figure 2)
 After installation, please wire in accordance with local connection standard, and make sure there are good joint protective measures.



Figure 1



Figure 2



B. Ceiling Mount:

 Use a chalk or sharp tool to mark the top of the ceiling or wall, then drill holes on the marks by electric drill (Figure 3).

2. Use a hammer to put the expansion screws into the holes (Figure 4).

 The holes on the bracket align with the expansion screws (Figure 5), then push the light to one side (Figure 6), finally tighten the nut of the screws.
 After installation, please wire in accordance with local connection standard, and make sure there are good joint protective measures.
 Users can adjust 50 degree to left or right in vertical direction by adjusting the screw on the bracket. (Figure 7).





Figure 3



Figure 5

Figure 4



Figure 6



Figure 7



C. M20 Mount

 Unscrew the nut on M20 (Figure 8).
 Make the corresponding holes on the bracket through the M20 (Figure 9).
 Re-cycle and tighten the nut (Figure

8) that unscrewed from the M20 (Figure 10).

4. After installation, please wire in accordance with local connection standard, and make sure there are good joint protective measures. (Figure 11).
Users can adjust 50 degrees to left and right in vertical direction by adjusting the screw on the bracket.





Figure 8

Figure 9





Figure 10

Figure 11