

NOTICE

*Please make sure that you have all part indicated and they are in good condition before you begin assembly of this item. Refer to part list and hardware list below for guidance.

*This item should be assembled on a soft surface to prevent scratching the finish during assembly.

*This item may require periodic tightening.

*If you are having difficulty, our friendly Customer Care team is always here to help. Please email customersupport@safavieh.com

PREPARATION

*Before beginning assembly of product, make sure all part are present. Compare part with part contents list and hardware contents list.

*If any part is missing or damaged, do not attempt to assemble the product.


*Estimated Assembly Time: 45 minutes.

*Tools Required for Assembly (Not included): Screwdriver

CARE AND MAINTENANCE


Always use felt pads under all articles to prevent discoloration or softening of the lacquer. Plastic and rubber bases on items can discolor wood. Wipe up spills immediately and avoid common hazards such as hot dishes, harsh solvents and abrasives. Cleaning should be done with a soft lint free cotton cloth dampened with water or furniture polish. On highly used surfaces we recommend applying a quality paste wax which should be used on a regular basis to provide additional protection from scratches and spills. How often you apply the wax depends on how much wear the furniture receives.

Part List



Model# COF3100

Product Dimensions: W 39.37" x D 21.65" x H 18.46"



WARNING :

WEIGHT CAPACITY :





Top : 47 Lbs

Shelf : 47 Lbs

Warning : Do not stand on the product.

Warning : Do not over torque bolts.

Hardware List

<div>Ax38</div> <div></div> <div>Ø6x32 mm</div>	<div>Bx38</div> <div></div> <div>Ø15x12 mm</div>	<div>Cx24</div> <div></div> <div>Ø8x32 mm</div>	<div>Sx19</div> <div>S (OAK) S1(WALNUT) S2(BLACK)</div> <div></div> <div>Ø20 mm</div>
--	---	--	--


Part List & HW

Piece	Description	Qty	Carton Call
1	Bottom Panel	1	1 of 1
2	Bottom Frame	3	1 of 1
3	Right Side Panel	1	1 of 1
4	Top Frame	3	1 of 1
5	Left Side Panel	1	1 of 1
6	Top Panel	1	1 of 1

Piece	Description	Qty	Carton Call
A	Cambolt	38	1 of 1
B	Camlock	38	1 of 1
C	Wooden Dowel	24	1 of 1
S	Cover Cap Sticker	19	1 of 1


PREPARATION

Before beginning assembly of product, make sure all part are present. Compare part with part contents list and hardware contents list.
If any part is missing or damaged, do not attempt to assemble the product.
Estimated Assembly Time: 45 minutes.




The diagram shows a rectangular bottom panel (1) with several pre-drilled holes. A circular inset provides a close-up of a cambolt (A) being inserted into one of these holes. To the right, a long wooden dowel (C) is shown with three pre-drilled holes, labeled 'x 3'. The dowel is also shown being inserted into the side of the bottom panel (1).

STEP1: Insert Cambolt (A) into bottom panel (1). Insert Wooden Dowel (C) into bottom panel (1), and bottom frame (2)




The diagram illustrates the assembly of the bottom frame (2) onto the bottom panel (1). The bottom frame (2) is a long, thin rectangular frame with multiple pre-drilled holes. A circular inset shows a camlock (B) being tightened onto one of the holes in the bottom frame (2) using a screwdriver. The bottom panel (1) is shown being aligned with the bottom frame (2) and secured with the camlock (B).

STEP2: Combine Bottom panel (1) into Bottom Frame (2) then tighten camlock (B) using screwdriver.




The diagram shows a rectangular side panel (3) with several pre-drilled holes. A circular inset provides a close-up of a cambolt (A) being inserted into one of these holes. To the right, a long wooden dowel (C) is shown with three pre-drilled holes, labeled 'x 3'. The dowel is also shown being inserted into the side of the side panel (3).

STEP3: Insert Cambolt (A) into side panel (3) Insert Wooden Dowel (C) into side panel (3), and top frame (4)




The diagram illustrates the final assembly step. The bottom panel (1) and the top frame (4) are being attached to the side panel (3). The bottom panel (1) is shown being aligned with the side panel (3) and secured with a camlock (B). The top frame (4) is shown being aligned with the side panel (3) and secured with a camlock (B). Arrows indicate the direction of movement for the panels and frame.


STEP4: Attach Bottom panel (1), and top frame (4) into Right side panel (3). Secure with Camlock (B) and tighten it using screwdriver.




STEP5: Insert Cambolt (A) into left side panel (5) Insert Wooden Dowel (C) into left side panel (5)



STEP6: Insert Left side panel (5) Secure with Camlock (B) and tighten it using screwdriver.



STEP7: Insert Cambolt (A) into top panel (6). Insert top panel (6), Secure with Camlock (B) and tighten it using screwdriver. Continue to attach the cover cap sticker (S) to the panel that has lamination



STEP8: Assembly is complete