



AN **ORIGINAL** GRANITE BRACKET™ PRODUCT **KNEE WALL COUNTERTOP SUPPORT BRACKET**

Our Knee Wall Countertop Support Bracket is the perfect concealed countertop overhang bracket for countertop support.



1. Mark 3"-6" from the outer edge of the knee/pony wall for your first pocket to be cut. Then set marks for the remaining brackets every 16"-20" apart for the best counter top protection.



2. Rout or chisel a 2.5" wide by 0.5" deep pocket on top of the knee/pony wall. This "pocket" will allow the bracket to sit flush with the top of the wall. (Make sure it is flush)



3. Once the "pocket" is made in the knee/pony wall, simply insert the bracket then screw the bracket into place making sure your screws are flush with the brackets.



4. Using a level, make sure your brackets are level; use shims where necessary until the brackets are completely level.



5. Place your counter top on top of the knee/pony wall and brackets.



6. Check once again that the counter top is level. Once level, caulk around the brackets with clear silicone to hold your counter top securely.



SCAN FOR
MORE PRODUCTS

ORIGINALGRANITEBRACKET.COM | 888-584-1112

***BRACKET COMES IN
MULTIPLE SIZES.**