


**PACKAGE CONTENTS**

ISSUED 10-2010

REVISED 2013-12-17

PART	DESCRIPTION	QUANTITY
A	Big Allen Wrench	1 pc
B	Small Allen Wrench	1 pc
C	Anchor Bracket	1 pc
D	Allen Bolt	3 pcs
E	Lock Ball	3 pcs
F	Washer	3 pcs
G	Lock Washer	3 pcs
H	Hex Nut	3 pcs
I	Anchor Bolt	3 pcs
J	Allen Set Screw	4 pcs
K	Post Fitter	1 pc
L	Upper Post	1 pc
M	Middle Post	1 pc
N	Bottom Post	1 pc



**! WARNINGS AND CAUTIONS**

**WARNING:**

- Before beginning the installation, turn off electricity at the circuit breaker box or the main fuse box by switching off the circuit breaker or removing the fuse.

**CAUTION:**

- These instructions are provided for your safety. It is very important that they are read completely before the installation of your fixture. We strongly recommend that a professional electrician install the fixture.
- Disconnect fixture from the power source before replacing the bulb(s), making sure that bulb(s) had sufficient time to cool down. DO NOT subject the lamp to any shock while lit as shattering of lamp may result.

**PREPARATION**


- Before beginning installation of product, make sure all parts are present. Compare parts with package contents list and diagram above. If any part is missing or damaged, do not attempt to assemble, install or operate the product. Contact customer service for replacement part.
- Estimated Assembly Time: 30 - 45 minutes
- Tool Required for Assembly (not included): Flathead screwdriver, Phillips screwdriver, Shovel, Electrical tape, Wire cutter, Safety glasses and proper length Wires (not supplied).
- Helpful Tools (not included): Wire strippers.

# INSTALLATION INSTRUCTIONS

STYLE NUMBER: PO9140XX


## STEP 1:

- Remove all Washers, Hex Nuts and Lock Balls from the Anchor Bolts.
- Screw the threaded end of each Anchor Bolt in the Mounting Bracket making sure to that the Anchor Bolt is 1.75" to 2" extended from the bottom of the Bracket.
- Place a Lock Washer over the Anchor Bolt and then thread the Hex Nut onto each Anchor bolt. Securing the Bracket in place maintaining the 1.75"-2" length of the Anchor Bolt.



## STEP 2:

- Dig a hole in the ground at the desired location for the Post Mount.
- Use cement to secure the Anchor Bolts into the ground making sure that the Bracket is flush on top of the cement and level Anchor at the desired grade with the ground. This is the base for the Post Mount.




## INSTALLATION INSTRUCTIONS

STYLE NUMBER: PO9140XX


### STEP 3:

- a. Place the Post Fitter on the Upper Post end without the threads. Secure the Post Fitter with (2) Allen Set Screw using the Small Allen Wrench provided.
- b. Thread the Upper Post assembly onto the Middle Post until secure. Secure the Upper Post assembly to the Middle post using (2) Allen Set Screw and the Small Allen Wrench provided.
- c. Place the Middle Post assemble onto the Bottom post lining up the mounting holes in the Middle Post assemble with the Bottom Post. Secure the Middle Post assembly to the Bottom Post using (2) Allen Bolt and the provide Big Allen Wrench. Tighten until secure.




### STEP 4:

- ★ Use Wire Connectors (not supplied) to connect the wires .
- a. Connect the House Ground Wire to the Fixture Ground Wire.
  - b. Connect the House White Wire to the Fixture Supply Wire (White or Ribbed Side).
  - c. Connect the House Black (or Red) Wire to the Fixture Supply Wire (Black or Smooth Side).
  - d. Wrap each connection with approved electrical tape carefully.



## STEP 5:

- a. Place the Post Mount assembly onto the Anchor Bolts. Place a Washer over each Anchor Bolt and secure each Anchor Bolt with the Lock Ball and tighten until secure.



Your installation is completed now. Restore electricity. Retain this sheet for future reference.