

DeckTok



USER MANUAL

Smart Outdoor String Lights

What You Get

ITEM	QUANTITY
Power Adapter	1
Control Box	1
String Light	1
User Manual	1


At a Glance



- Click once to switch the mode
- Click twice to turn off/on the light
- Long press for 5 seconds red light flashing in connection network mode


Control String Lights In Series

Connect the string lights as illustrated



Installing Your Outdoor Light

Use the hook to hang the light bulb on the rope



Setting Up The System

1. Download the Decktok App from APP Store in Apple iPhone / APP market in Android mobile phone.



2. Connect to a 2.4GHz WiFi network and turn on your smartphone's Bluetooth.
3. Long press the on/off button of the control box for 5 seconds. When the red light flashes, you can open the app to connect to the network.
4. Click Add Device or click + icon on the upper right corner of the APP home page, to choose Add Device and enter the Add interface for selecting the device to be added.
5. When the device is connected to the network, the Add device interface will automatically pop up the device icon. Tap the device icon and follow the on-screen instructions to complete pairing.

Specifications

Adapter Input	AC 100-240V ~50/60HZ
Adapter Output	5V/2A
Length	45FT
Number Of Bulbs	15
Light Color	RGB
wireless Protocol	2.4GHz Wi-Fi + Bluetooth
Waterproof	IP65
Working Temperature	-4°F-104°

Notice

- Use the product with the provided power adapter only.
- Do not allow children to assemble or install this product.
- Avoid installing this product in a closed environment or near large heat sources.
- Ensure the cables are installed without overstretching.

Troubleshooting

1. Unable to connect to the App

- Ensure the light strip is powered on.
- Check if Bluetooth is enabled on your phone.
- Make sure your phone is connected to a 2.4GHz Wi-Fi network.
- Long-press the control box button for five seconds until the red light flashes to activate pairing mode.

2. The light does not glow

- Unplug the power adapter, disconnect and reconnect all components, then plug the power adapter back in.
- If the issue persists, please contact DeckTok's official customer service.



Customer Service

Warranty: 12-month Limited Warranty

 www.decktok.com

 info@decktok.com