
ASSEMBLY INSTRUCTIONS 36" BATHROOM VANITY



Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware.

Compare with the parts list to be sure all parts are present.

"DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED"



- * Use of power tool to assemble this product will invalidate any claim and damage this product making unsefe!!
- damage this product making unsafe !!!

 * Please assemble on a clean soft surface to avoid damage.







Tools Required



(Not included)



IMPORTANT:

PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY

PLEASE DO NOT RETURN TO STORE



Please do not return this product to the retailer!!

We are able to assist you in ANY way

If you find that you have any trouble with assembly or missing or damaged parts please contact the seller.


Before Installation

Important – Please read these instructions fully before starting assembly

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.

- We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
- Please do not over tighten screws or bolts until the assembly is completed.
- Keep children and animal away from the work area, small parts could choke if swallowed.
- Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

Cam Lock Assembly Instructions



Detail View - CABINET 8 6 (10) 1 13 12 20 (22) 23 **(21)** 25) **(27) (23) 14**)


Identifying the Hardware-Identify the hardware using the illustrations below.


Part List				
1	2			
Side Panel (L) - 1pc	Side Panel (R) - 1pc			
3	4			
Mid Panel - 1pc	Side Panel Top (L) - 1pc			
5	6			
Side Panel Top (R) - 1pc	Crossbar Top - 1pc			
7	8			
Panel Top Rear - 1pc	Flip Drawer - 1pc			
9 Flip Drawer Face - 1pc	Frame Mid - 1pc			
Rear Panel Bottom - 1pc	Bottom Panel - 1pc			
13	14			
Adjustable Shelf - 1pc	Door - 1pc			

Part L	ist		
15		16	
	Left Panel of Door - 1pc		Right Panel of Door - 1pc
17		18	
	Mid Panel of Door - 2pcs		Round Bar - 2pcs
19		20	
	Drawer Front Top - 1pc		Drawer Rear Top - 1pc
21		22	
	Drawer Side Top(L) - 1pc		Drawer Side Top(R) - 1pc
23		24	
	Drawer Bottom - 2pcs		Drawer Front Bottom - 1pc
25		26	
,	Drawer Rear Bottom - 1pc		Drawer Side Bottom (L) - 1pc
27			
	Drawer Side Bottom (R) - 1pc		


Hardware List


Α	B	С
		(S)mmmm>
ø6x35mm	ø14.5x12mm	ø8xø4x25mm
Three in one bolts(36pcs)	Three in one lock(36pcs)	Round head screw(4pcs)
D	E	F
	90	(S)
ø8xø4x32mm		ø5/32"x20mm
Round head screw(24pcs)	Handle(5pcs)	Handle screw(1pc)
G (2011) 25 rare	H	I
ø5/32"x25mm Handle screw(4pcs)	Duo Forte (1pc)	Rotary Hinge(2pcs)
J ø6xø3x12mm	K	L ⊕ ⊕ ⊕ ⊕ ⊕ ⊕ ⊕ ⊕ ⊕ ⊕ ⊕ ⊕ ⊕ ⊕ ⊕ ⊕ ⊕ ⊕ ⊕
Flat head screw(8pcs)	Damping hinge (2pcs)	Flat head screw(12pcs)
M	N Ø8x30mm	0 8 8
Laminate pad(4pcs)	Wood dowel(36pcs)	Anti fall hardware(1set)
















STEP: 5





























STEP: 20






STEP: 21




STEP: 22






HINGE ADJUSTMENTS



1 Sideways / Tilt adjustment


Turn the screw clockwise to move the door further away from the side of the cabinet anticlockwise to move the door closer to the side of the cabinet



2 4 Height adjustment

While supporting the weight of the door, turn the screws

clockwise to move the door up anticlockwise to move the door down



3 Forward and back adjustment

If the gap between the back of the door and the cabinet is too small, and the door may not close fully. Turn the screw

clockwise to decrease the gap between the door and the cabinet

anticlockwise to increase the gap between the door and the cabinet

