Kitchen Island Cart

Assembly Instructions - Please keep for future reference N707P263094



OPTION WITH THE FEET



OPTION WITH THE WHEELS

Important - Please read these instructions fully before starting assembly



Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



• To reduce the likelihood of damaging your product please ensure that your

power drill is set on a low torque setting.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste.
 Take to your local authority waste disposal centre.

Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure That all bolts and fittings are tightend properly.

WARNING In order to help prevent overturning – please follow these instructions

To help prevent product toppling over please follow the below steps:-

Use the anti tip stap or wall fixing method provided (if applicable)

Do not allow children to climb or hang on the furniture

Do not open more than one drawer at a time

Do not place heavy items in the top drawers

Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose

Components - Fittings

Please check you have all the panels listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases, more fittings may be supplied than required.

| A QTY: 32 | B QTY: 32 | C QTY: 8 | D QTY: 24 |
|---|--|--------------------|-------------------------------------|
| | | | <aaaaaaa(\$)< th=""></aaaaaaa(\$)<> |
| | | Ø8*30mm | Ø6*12mm |
| CAM BOLT QTY: 122 | CAM LOCK QTY: 4 | WOOD DOWEL QTY: 4 | FLAT HEAD SCREW |
| E Q14: 122 | F1 | F2 | G QTY: 4 |
| << <a><a><a><a><a><a><a><a><a><a><a><a><a< th=""><th>The state of the s</th><th></th><th></th></a<> | The state of the s | | |
| FLAT HEAD SCREW | BALL BEARING GLIDE | BALL BEARING GLIDE | RUBBER STOPPER |
| CL QTY: 3 | DL QTY: 3 | DR QTY:3 | CR QTY: 3 |
| 000000000000000000000000000000000000000 | 000 | 90 SUGG | 00 T 00 00 T 00 |
| ROLLER RUNNER | ROLLER RUNNER | ROLLER RUNNER | ROLLER RUNNER |
| H QTY: 8 | QTY: 7 | J QTY: 8 | K QTY: 20 |
| | | | (X) |
| | | | Ø6*25mm |
| SHELF PIN QTY: 2 | HINGES QTY: 4 | HINGES QTY: 10 | FLAT HEAD SCREW |
| L | M QIY.4 | N | O QTY: 20 |
| | | | Ø8*20mm |
| LIA ONET | MAGNIET SUATE | | BOLT 3 |
| MAGNET | MAGNET PLATE | HANDLE | BOLT 3 |

Components - Fittings

Please check you have all the panels listed below


Note: The quantities below are the correct amount to complete the assembly. In some cases, more fittings may be supplied than required.

| P QTY: 1 Q QTY: 5 R QTY: 1 S QTY: 2 ALLEN WRENCH LOCK CASTER CAM TOOL SPRING BALL LATCH T QTY: 10 U QTY: 20 V QTY: 10 W QTY: 10 Ø1/4*32mm Ø1/4*12mm BOLT SPRING WASHER FLAT WASHER X QTY: 1 Y QTY: 8 Ø10*45mm Ø10*45mm SOCKET ALLEN FLAT HEAD SCREW | | | | | |
|--|--------------|-----------------------|----------------|-------------------|--|
| ALLEN WRENCH T QTY: 10 QTY: 20 QTY: 10 W QTY: 10 W QTY: 10 ALLEN WRENCH T QTY: 10 | P QTY: 1 | Q QTY: 5 | R QTY: 1 | S QTY: 2 | |
| T QTY: 10 U QTY: 20 V QTY: 10 W QTY: 10 Ø1/4*32mm Ø1/4*12mm BOLT SPRING WASHER FLAT WASHER Χ QTY: 1 Υ QTY: 8 Ø10*45mm Ø10*45mm | | | | | |
| Model W Model Mod | ALLEN WRENCH | LOCK CASTER | CAM TOOL | SPRING BALL LATCH | |
| BOLT SPRING WASHER FLAT WASHER X QTY: 1 Y QTY: 8 Ø10*45mm | T QTY: 10 | U QTY: 20 | V QTY: 10 | W QTY: 10 | |
| BOLT SPRING WASHER FLAT WASHER X QTY: 1 Y QTY: 8 Ø10*45mm | @1/4*32mm | ©1/4*12mm | | | |
| X QTY: 1 Y QTY: 8 Ø10*45mm | | | SDRING WASHER | ELAT WASHED | |
| Ø10*45mm | OTV. 1 | Y QTY: 8 | OF KING WASHER | TEAT WASHEN | |
| SOCKET ALLEN FLAT HEAD SCREW | | | | | |
| | SOCKET | ALLEN FLAT HEAD SCREW | | | |

Using Camlocks


Step 1

Connect the male camlock as diected in the assembly instructions using a scewdriver.



Step 2


Push the male camlock into the entry hole.



Step 3

Insert the female camlock as shown in the instruction.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.




Step 4

Turn the female camlock clockwise with a screwdriver.

You should feel a click when the camlock is locked in place.


The joint is now secure.





COMPONENTS - KEY DIAGRAM) (11) 9x5 x2pcs

COMPONENTS - KEY DIAGRAM

x2pcs








| COMPONENTS - KEY DIAGRAM | | | | | |
|--------------------------|--------|---------------------|--------|-----------------------------|--|
| 16 | | 17 | | 18 | |
| BRACKET - LEFT | QTY: 1 | BRACKET - BOTTOM | QTY: 1 | RIGHT PULL BAR QTY: 3 | |
| 19 | | 20 | | 21 | |
| BRACKET - RIGHT | QTY: 2 | RIGHT PULL BAR | QTY: 1 | DRAWER FRONT - LARGE QTY: 2 | |
| | | 23 | | | |
| DRAWER SIDE - LARGE | QTY: 2 | DRAWER SIDE - LARGE | QTY: 2 | DRAWER BACK - LARGE QTY: 2 | |
| 25 | | 26 | | 27 | |
| DRAWER BOTTOM - LARGE | QTY: 2 | BRACKET - LEFT | QTY: 1 | DRAWER SIDE - SMALL QTY: 2 | |
| 28 | | 29 | | 30 QTY: 3 | |
| DRAWER SIDE - SMALL | QTY: 2 | DRAWER BACK - SMALL | QTY: 2 | DRAWER BOTTOM - SMALL | |
| | | | | 9 | |


| COMPONENTS - KEY DIAGRAM | | | | | |
|--------------------------|---------------------------|----------|----------------------|--------|--|
| 31 | 32 | | 33 | | |
| DRAWER FRONT - BOTTOM Q | TY: 1 DRAWER SIDE - BOTTO | M QTY: 1 | DRAWER SIDE - BOTTOM | QTY: 1 | |
| 34 | 35 | | | | |
| DRAWER BACK - BOTTOM Q | TY: 1 PLASTIC SPLINT | QTY: 2 | | | |


Slides Must Be Separated Before Assembly. After Separated, Set Aside Until Needed for Assembly.


Las diapositivas deben separarse antes del montaje. Después de la separación, déjelo a un lado hasta que sea necesario.

Les glissières doivent être séparées avant l'assemblage. Après la séparation,mettez de côté jusqu'au moment de l'assemblage.




















| _ | | 2PCS |
|---|---|------|
| Е | | 6PCS |
| S | 0 | 1PC |




















ASSEMBLY INSTRUCTIONS


STEP 15








ASSEMBLY INSTRUCTIONS STEP 18 E E XΕ 2PCS Χ 1PC




Ν


6PCS



ASSEMBLY INSTRUCTIONS


STEP 21 x2 Set







| D | (X) | 12PCS |
|----|--------------|-------|
| F2 | The state of | 4PCS |

STEP 22 x2 Set




| Α | 8PCS | | | |
|---|------|---|----------|-----|
| В | 8PCS | K | * | 8PC |






ASSEMBLY INSTRUCTIONS


STEP 27







NOTE: Pull the inner ball bearing slides on each side all the way out till it stops. (may be slightly greasy)


STEP 28









STEP 31



COMPLETED!



OPTION WITH THE FEET



OPTION WITH THE WHEELS