


# ASSEMBLY INSTRUCTION

## GAZEBO

N715P261157



# Read Manual

Your gazebo Frame requires assembly prior to use. It is important that you read the entire manual to become familiar with the unit BEFORE you set up the gazebo Frame.

## Safety Warning and Precautions

**WARNING:** When using product, basic safety precautions should always be followed to reduce the risk of personal injury and damage to equipment.

### Read all instructions before assembly and usage this product

- 1. Select ideal location.** Set out all parts on a clear and level surface prior to assembly. Ideally, the gazebo Frame should be set up in the desired location to avoid moving it after assembly.
- 2. Use caution.** During all the processes of assembling, especially when lifting heavy or large parts, pay attention to safety.
- 3. Tools and Assistance.** Ladder and Phillips screwdriver are self-provided. Whenever possible, assistance is preferred.
- 4. Check for parts available.** Before assembling your gazebo Frame, make sure that you have all parts described in the Parts List.
- 5. Check for damaged parts.** Before assembling your gazebo Frame check for damaged parts. Any part that appears damaged should be carefully checked to determine if it can be operated properly and perform its intended function. Any part that is damaged should be properly repaired or replaced by a qualified technician.
- 6. Refer to assembly diagram.** During assembly, it will be helpful to refer to the assembly diagram.
- 7. Keep children away.** Children shouldn't be allowed in the work area. Do not let them handle parts and tools. No people should be permitted to enter into work area except who is working.


**Note! This gazebo is meant to be used for Decorative and sunshade purposes only and is not meant to withstand all elements of the weather. Please remove all FABRIC during inclement weather.**

# N715P261157

## PART LIST


A x4pcs

Leg



B x4pcs

Ring Beam 1




B2 x4pcs

Ring Beam 2




C x4pcs

Four-corner Upward Sloping Tube




D x4pcs

Four-corner Downward Sloping Tube




E x2pcs

Sino-slanting Tube 1




E2 x2pcs

Sino-slanting Tube 2




F x8pcs

Corner Support




H x1pcs

Eight-claw Top




N x4pcs

Four-corner Support




K x4pcs

Feet




P x4pcs

Ring Beam Connectors




O x4pcs

Middle Support




Z1 x1


Cloth Roof



Z2 x4  
Tulle




Z3 x4  
Sidewall



## N715P261157 HARDWARE LIST


1# M6\*15 x32+2  
Bolt 1



2# M6\*30 x64+2  
Bolt 2



3# M6 x40+2  
Nut



4# x88+2  
Plastic Opening Ring



Q x8  
Ground Spike




S1 x1  
Hex Wrench



S2 x1  
Wrench




# REFERENCE IMAGE



# STEP 01

x4



Ax4


Nx4

Kx4

1#x8


# STEP 02

x2



Bx4	B2x4			
0x4	Px4	1#x8	2#x16	3#x24

# STEP 03




Fx8

1#x16

2#x32




STEP 04



2#x8	3#x8			
Hx1	Cx4	Dx4	Ex2	E2x2


# STEP 05



2#x8


3#x8

# STEP 06



Z1x1

# STEP 07



Z2x4

Z3x4

Qx8

4#x88