

Remote View Setup

To set up remote viewing, you need to install the Eseecloud App and register an account. This allows you to access live feeds from your security cameras from anywhere.





EseeCloud(IP Pro, VR Cam)

Guangzhou Juan IOT Technology
Co.,Ltd
Contains ads

Uninstall

Open

Available on more devices



Samsung SM-A125U
Phone

Install

Install Eseecloud App

1 Download


Visit the App Store or Google Play Store to download the Eseecloud App on your smartphone or tablet. 2 Installation

After downloading, follow the on-screen instructions to complete the installation process.

3 Login


Once installed, create an account using your details.

ponsored · Suggested for you



Eseecloud

Welcome to EseeCloud



Creat Account

Create Account

Enter your phone number or Email, set up a password, and fill out the necessary registration information.

Verification

Verification Code will be sent to you.



Eseecloud

Welcome to EseeCloud

Phone number

Account

Phone number

+1 ▼

Enter phone number

Verification code

Verification code

87s

Login

Login to agree 《User Agreement》 《Privacy Policy》

Account Verification

1 Verification Code


Check your text messages or email inbox (including the spam folder) for a verification code, and enter the code or click on the link to verify your account.

2 Complete Setup

Once verified, you'll be directed to complete your account setup within the Eseecloud App.

Device Group





Camera network configuration demo




Add New Device

Add new device

After logging in, select the '+' sign or choose the 'Add camera' option.

Device Cloud ID

Enter the unique Cloud ID, which can be located in your NVR system under 'System Setting > Network' (Old UI) or 'System Setup > App/account' (New UI).



Please turn on nearby devices



The current application lacks relevant permissions and cannot search for nearby devices through Bluetooth

Cancel

Enable

Click "Cancel"


** Skip this step if you are an iPhone user.




Please turn on Bluetooth to automatically find nearby devices.

Enable

More ways to add




Swipe up on the screen to view more options



There are three options for adding a new device

Scan to add, Camera ID add, LAN scan



A. Scan to Add

QR Code

Scan the QR code shown on your NVR screen, which can be found within your NVR system under 'System Setting > Network' (Old UI) or 'System Setup > App/account' (New UI).

If scanning is not possible due to screen glare, please use another option to add your device.

ADD by ID



The ID number can be found next to the QR code label on the body of the device

Live Chat



B. Camera ID add

Manual Entry

If necessary, manually input the Cloud ID to connect the device to the app.

Use your NVR User name and password

The username and password will be the same as those used for your NVR.

Search device










C. LAN scan

Access LAN Settings

Within the options, select 'LAN Scan' to search for your local device.

Device List

After scanning, a list of local devices will appear. Select the ones you wish to add.



Complete Setup

Final Review

Ensure that all your NVRs are correctly connected to your home router via Ethernet cable or Wi-Fi and are operating as expected.

Remote View

To begin remote monitoring of your cameras, just click the play button in your app.