




HIDE IT WITH STYLE



Waverly Screen Kit

36" W x 44" H

45 min
Approximate assembly
time for 2 screens



Scan the QR code
for an assembly video



ASSEMBLY INSTRUCTIONS

EC18010 (WHITE COLOR)

EC18011 (CEDAR COLOR)

www.encloscreens.com

VER. 092022

GENERAL INFORMATION



IMPORTANT

- ◀ Check the inside of the larger pieces in your box for other materials packed inside.
- ◀ When assembling components, place on a non-abrasive surface (i.e. shipping box) to avoid scratching.
- ◀ We recommend an area approximately 5'x 8' for unobstructed assembling.
- ◀ You should not need to use excessive force when assembling components.

MISSING OR DAMAGED PARTS?

VISIT OUR WEBSITE FIRST, SO WE CAN HELP YOU RIGHT AWAY!

Although great care has been taken to ensure proper packaging and handling of this product, occasionally problems occur. If you discover any missing, damaged, or defective parts, please visit our website to order replacement parts. If you experience any further trouble with your product, please contact our customer service department.

 parts.nychbrands.com

 support@encloscreens.com

 **704-892-5222 / 877-234-6196**

Customer service agents are available to take calls weekdays from 9am-5pm EST. If you call outside of business hours, please leave a voicemail.

To help you quickly and accurately, please have reference item number **EC18010 (WHITE COLOR)** / **EC18011 (CEDAR COLOR)** and the specific part name which can be found on page 5. It is helpful if you can provide the batch lot which is a stamped number on the end of the box.


NEED ASSEMBLY HELP?

If you are having problems with the assembly or installation of this product, we are happy to assist you with the process, **so please give us a call at 704-892-5222 / 877-234-6196**

NEED TO RETURN?


If for some reason you need to return this product, please allow us to help resolve your issues first. If you still decide to return the product, **you will need to initiate the return from the company you originally purchased from.**

Detailed Product Dimensions & Specifications




STEP 1: LAY OUT TOOLS


► Tools required for a smoother installation experience.



► **Drill**




► **Mallet***




► **Wood Block***

**- May be needed depending on soil condition*

OPTIONAL



► **1 3/4" Tulip Auger***




► **Level**

**- May be needed depending on soil condition*

STEP 2: LAY OUT MATERIALS**A**

Ground Stake (4)
 $\frac{3}{4}" \times 1 \frac{1}{4}" \times 14"$

B

Slat (22)
 $.4" \times 2.875" \times 35 \frac{7}{8}"$

C


Rail (4)
 $\frac{7}{8}" \times 1 \frac{1}{2}" \times 35 \frac{7}{8}"$

D


Left Post (2)
 $1 \frac{1}{2}" \times 1 \frac{1}{2}" \times 44"$

E

Right Post (2)
 $1 \frac{1}{2}" \times 1 \frac{1}{2}" \times 44"$

F

Joiner Clip (2)
 $\frac{1}{13}" \times \frac{3}{4}" \times 1 \frac{3}{4}"$

G



$\frac{3}{4}"$ Self-Drilling Stainless Steel Screw (28)

STEP 3: ASSEMBLE THE PANEL

STEP 3.1



1. Slide (2) Rails (C) into the routed holes in the Left Post (D).
2. Slide (11) Slats (B) into the angled slots in the left post.

Tip: Brace the left post against a wall or raised flat surface to allow for easier installation in future steps.



STEP 3.2


1. Slide (1) Right Post (E) over the opposite ends of the slats and rails. Ensure the rails and slats are tight to the back of both posts and that the unit is square before driving in screws.
2. Drive (8) total 3/4" Self-Drilling Stainless Steel Screw (G) into the pre-drilled holes in the posts.



STEP 4: INSTALL THE GROUND STAKES

STEP 4.1


1. Slide (2) Ground Stakes (A) up into the bottom of the posts until the pre-drilled holes in the stakes and posts align.
2. Drive (4) total $\frac{3}{4}$ " self-drilling stainless steel screw into the pre-drilled holes.



STEP 5: ASSEMBLE THE SECOND SCREEN PANEL

STEP 5.1

- Repeat Steps 2-3 in order to assemble the second screen.





STEP 6: INSTALL PANELS IN THE GROUND

STEP 6.1


1. Move the screen to its final location, and identify the location of the posts.
2. Attempt to push the unit into the ground. All 10" of the ground stakes should go in the ground.
3. Ensure the unit is properly leveled.

Note: If you face resistance refer to the instructions in the next step. Excessive force can damage the top of the posts.



STEP 6.2




1. If your ground is too hard, loosen the top 6" or 7" of the ground with a claw hammer as illustrated.
2. Add water to the loosened soil.
3. Use a block of wood to protect the top of the post and gently hammer the post into the ground.



STEP 6.3

► **Optional in hard ground:** If your ground is too hard, or you have more than 3 or 4 panels to install, please consider these options:

1. Use a 1¼" diameter auger bit (commonly used for planting tulips) as illustrated (\$15-\$20 on Amazon.com).
2. Drill a hole about 12" to 16" deep at the desired location, and fill the holes with water as illustrated.
3. Push the panel posts into the holes.


1**2****3**

STEP 7: CONNECT THE SCREENS

STEP 7.1

1. **Straight Line Application:** Connect the screens as shown below using Joiner Clips (**F**) and $\frac{3}{4}$ " self-drilling stainless steel screws.
2. **Corner Application:** Connect the screens as shown below using Joiner Clips (**F**) and $\frac{3}{4}$ " self-drilling stainless steel screws.

Note: There are no pre-drilled holes for the joiner clips to allow for greater customization during assembly.





HIDE IT WITH STYLE

www.encloscreens.com

support@encloscreens.com



704-892-5222
877-234-6196



6935 Reames Rd. Ste. K.
Charlotte, NC 28216



ASSEMBLY INSTRUCTIONS

EC18010 (WHITE COLOR)
EC18011 (CEDAR COLOR)