

NOTICE

- * Please make sure that you have all parts indicated and they are in good condition before you begin assembly of this item. Refer to part list and hardware list below for guidance.
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly.
- * This item may require periodic tightening.
- * If you are having difficulty, our friendly Customer Care team is always here to help. Please email customersupport@safavieh.com













PREPARATION

- * Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.
- * If any part is missing or damaged, do not attempt to assemble the product.
- * Estimated Assembly Time: 45 minutes.
- * Tools Required for Assembly (included): Allen Key

CARE AND MAINTENANCE


Adhesive felt pads should always be applied to areas of furniture which make direct contact with flooring, said application will prevent damage to the furniture and or surfaces on which the furniture lies. Objects placed on articles of furniture should rest on non abrasive material as to prevent damage to the wood finish. Wipe up spills immediately and avoid common hazards such as hot dishes, harsh solvents and abrasives. Cleaning should be done with a soft lint free cotton cloth dampened with water or furniture polish.

Part List and Hardware List










PIECE	DESCRIPTION	PICTURE	QUANTITY
A	TOP PANEL		1X
B	LEFT PANEL		1X
C	RIGHT PANEL		1X
D	BOTTOM ASSEMBLY		1X
E	BACK PANEL		1X
F	LEG FRAME		2X
G	SIDE FRAME		2X
H	DRAWER FRONT		2X
I	DRAWER LEFT		2X
J	DRAWER RIGHT		2X
K	DRAWER BACK		2X
L	DRAWER BASE		2X



Model# NST5007
Product Dimensions: 18"W x 16"D x 23"H




WEIGHT CAPACITY, TOP: 50 LBS, DRAWER: 15 LBS
WARNING: DO NOT STAND ON THE NIGHT STAND
WARNING: DO NOT OVER TORQUE BOLTS/SCREWS

PIECE	DESCRIPTION	PICTURE	QUANTITY
HW1	BOLT 6 x 1 x 25 MM		12X
HW2	FLAT HEAD SCREW 3 x 1 x 32 MM		16X
HW3	FLAT HEAD SCREW 3 x 1 x 19 MM		8X
HW4	FLAT HEAD SCREW 3 x 1 x 16 MM		8X
HW5	CAMBOLT		12X
HW6	CAMLOCK		12X
HW7	DOWEL		8X
HW8	WEDGE		8X
HW9	ALLEN KEY		1X


PREPARATION

- * Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
- * If any part is missing or damaged, do not attempt to assemble the product.
- * Estimated Assembly Time: 45 minutes.
- * Tools Required for Assembly (included): Allen Key
- * If you are having difficulty, our friendly Customer Care team is always here to help. Please email customersupport@safavieh.com


<p>The diagram shows two rectangular panels, labeled A (top) and D (bottom). Panel A is shown with four cambolts (HW5) being inserted into pre-drilled holes along its perimeter. Panel D is shown with four cambolts (HW5) being inserted into its perimeter. A screwdriver icon is shown next to one of the cambolts being inserted into panel A.</p>	<p>The diagram shows three panels: A (top), B (left), and C (right). Panel B is being attached to panel A using camlocks (HW6) and dowels (HW7). Panel C is being attached to panel A using camlocks (HW6) and dowels (HW7). A circular inset shows a close-up of a camlock (HW6) being rotated 180 degrees. Another circular inset shows a close-up of a camlock (HW6) being inserted into a hole in panel A, with a checkmark indicating the correct orientation and an X indicating the incorrect orientation.</p>
<p>STEP 1 ATTACH CAMBOLTS (HW5) TO TOP PANEL (A) AND BOTTOM ASSEMBLY (D).</p>	<p>STEP 2 ATTACH LEFT PANEL (B) AND RIGHT PANEL (C) TO TOP PANEL (A) USING CAMLOCKS (HW6) AND DOWELS (HW7).</p>




STEP 3 SLIDE BACK PANEL (E) INTO THE GROOVE OF UNIT.




STEP 4 ATTACH BOTTOM ASSEMBLY (D) TO UNIT USING CAMLOCKS (HW6) AND DOWELS (HW7).




STEP 5 ATTACH LEG FRAMES (F) TO SIDE FRAMES (G) USING 25 MM BOLTS (HW1).
TIGHTEN BOLTS USING ALLEN KEY (HW9).




STEP 6 ATTACH UNIT FROM STEP 5 TO UNIT FROM STEP 4 USING 25 MM BOLTS (HW1).
TIGHTEN THE BOLTS USING ALLEN KEY (HW9).





STEP 7 ATTACH WEDGES (HW8) TO UNIT USING 5/8" FLAT HEAD SCREWS (HW4). ADJUST THE ADJUSTER THAT HAS ALREADY BEEN ASSEMBLED TO THE LEGS TO STABILIZE YOUR UNIT.




STEP 8 ATTACH DRAWER LEFT (I) AND DRAWER RIGHT (J) TO DRAWER BACK (K) USING 1 1/4" FLAT HEAD SCREWS (HW2). SLIDE DRAWER BASE (L) INTO THE GROOVE. ATTACH DRAWER FRONT (H) TO DRAWER LEFT (I) AND DRAWER RIGHT (J) USING 1 1/4" FLAT HEAD SCREWS (HW2).




STEP 9 LOOSEN SLIGHTLY THE SCREWS PRE-INSTALLED ON THE BACK OF THE DRAWER FRONTS.



STEP 11 PULL THE DRAWER OPEN SLOWLY AND RE-TIGHTEN THE SCREWS FROM STEP 9. MAKE SURE THE FRONT PANEL DOES NOT MOVE AND LOCK THE DRAWER FRONT PANEL INTO POSITION WITH 3/4" FLAT HEAD SCREWS (HW3).



STEP 10 INSERT THE DRAWER INTO THE UNIT, THEN ADJUST THE DRAWER FRONT PANEL LEFT OR RIGHT AND UP OR DOWN UNTIL THE DRAWER GAPS LOOK PROPORTIONAL.



STEP 12 SLIDE THE DRAWERS INTO UNIT.