


Resin Garden Shed

OWNER'S MANUAL

Instructions for Assembly



SLD-F35

Requires three people and takes 3-4 hours for
Installation. Quick & Easy Assembly

Ridge Reinforced Walls

Available in Various Sizes

BEFORE YOU START

Owner's Manual

Prior to installation, it is important that you contact your local government authority to determine if building approval is required. Study and understand this owner's manual. Important information and helpful tips will make your construction easier and more enjoyable.

Assembly instructions

Instructions are supplied in this manual and contain all appropriate information for your building model. Review all instructions before you begin. During assembly, follow the step sequence carefully for correct results. Please be aware: **this unit takes two people about one full day to complete.**


Parts

Check to be sure that you have all the necessary parts for the building.

Separate contents of the carton by the part number while reviewing parts list.


Familiarize yourself with the hardware and fasteners for easier use during construction. These are packaged within the carton. Note that extra fasteners have been supplied for your convenience.

TOOLS MAY REQUIRED



Use heavy duty gloves when handling steel sheets and flashing

PLAN AHEAD



It requires two people a full day to complete installation

Watch the weather:

Please be sure the day you select for installation is dry and calm.

DO NOT attempt to assemble your shed in windy weather because of risk of damage to panels, or personal injury. Be careful of wet or muddy ground.

Teamwork:

Whenever possible, two or more people should work together to assemble the building. One person can position parts or panels while the other is able to handle the fasteners and the tools.

PLAN AHEAD

Site Selection

- Avoid overhanging trees as much as possible as leaves will make regular cleaning necessary and broken branches are a potential hazard.
- Small trees, bushes or fences nearby can be helpful, acting as a wind break.

Site Preparation

The site must be prepared so that the base of the shed is level all round and checking with a spirit level is required.

The base can be constructed by treated timber or concrete, in order to stop the moisture getting into the shed. **The shed is not designed to be built onto lawn directly.** Also the ground will get muddy during rainy days.

If a concrete pad is made, it is important that this slopes towards the edges to prevent water ingress.

Time must be allowed for any concrete or cement to dry before building the shed on top.










Bases can also be constructed from bricks, blocks, or mounted on a concrete pad.


The bricks or blocks should be cemented onto firm and level concrete footings and the greenhouse frame drilled and screwed to the base.

IMPORTANT NOTES:




















- Find someone to help you: it is much easier with someone to hold parts, pass tools etc. Also some steps require two people to lift structures together. This is not very heavy work so would suit most able-bodied people.
- Allow plenty of time: rushing often causes errors and the re-doing of incorrect assemblies. If you have never built a shed before, it can take most of a day to carefully complete the construction.
- Have the right tools to hand.
- Safety clothing as recommended in the 'Tools' section.
- Ideally lay out the parts and check that all are present before commencing construction. Lay on cloths or plastic sheets if there is any risk of scratching the parts.
- Tighten all nuts carefully, being sure not to miss any. Check the frame is square and using a spirit level to check that it is upright.



BASEMENT COMPONENTS

F35-C01 	F35-C02 	F35-C03 	F35-C24-1 
310*1495*14mm 1PC	280*1495*14mm 1PC	310*1495*14mm 1PC	43*45*629mm 1PC
F35-C27 	F35-C28 	F35-C19 	F35-C20 
101*101*36mm 3PCS	101*101*36mm 1PC	43*43*835mm 1PC	43*43*860mm 2PC
F35-C21 			
43*43*1465mm 1PC			










WALL COMPONENTS

F35-C08 	F35-C09 	F35-C10 	F35-C11 
492*1495*14mm 1PC	310*850*14mm 1PC	310*850*14mm 3PCS	122*850*14mm 1PC
F35-C12 	F35-C13 	F35-C14 	F35-C15 
310*890*14mm 10PCS	310*890*14mm 1PC	310*890*14mm 1PC	492*1495*14mm 1PC
F35-C16 	F35-C22 	F35-C23 	F35-C25 
310*1495*14mm 4PCS	33*33*1825mm 2PCS	33*33*1710mm 2PCS	57*34*22mm 1PC
F35-C26 	F35-C31 	F35-C32 	F35-C33 
62*34*22mm 1PC	412*560*18 1PC	540*390*13 1PC	348*498*2.0 1PC
F35-A01 	F35-A02 	F35-A03 	
41*18.5*1700mm 1PC	61*2.05*1698mm 1PC	25*44*663mm 1PC	














ROOF COMPONENTS

F35-C06 	F35-C07 	F35-C17 	F35-C18 
380*1580*14mm 1PC	310*1580*14mm 2PCS	75*54*1480mm 2PCS	75*54*890mm 2PCS
F35-C30 	F35-A08 		
100*100*45mm 4PCS	935*66*16mm 1PC		







DOOR COMPONENTS




F35-C04 	F35-C05 	F35-C29 	
415*606*14mm 1PC	310*606*14mm 4PCS	47*47*21mm 4PCS	
F35-D01 	F35-D02 	F35-A04 	
70*40mm 3PCS	62*30mm 1PC	36*17*609mm 2PCS	
F35-A05  18*27*1630mm 1PC			
F35-A06  18*27*1630mm 1PC			





SCREWS



E01	E02	E03	E04
			
4.2*12mm 38PCS	4.2*12mm 205PCS	4.8*19mm 24PCS	5.5*50mm 4PCS



ASSEMBLY



1	F35-C01	F35-C02	F35-C03
	 X1	 X1	 X1













2	E02  X6	
---	--	--








3	F35-C20  X2	E02  X4
---	--	--








4	F35-C24-1  X1	F35-C27  X3	F35-C28  X1	F35-C19  X1	F35-C21  X1	E02  X12
---	--	--	--	--	--	---













5	<p>F35-C09</p>  <p>X1</p>	<p>F35-C10</p>  <p>X3</p>	<p>F35-C11</p>  <p>X1</p>	<p>E02</p>  <p>X8</p>
---	--	--	---	--













6	F35-C16  X4	F35-C15  X1	E02  X8
---	---	---	---












7	F35-C12  X5	F35-C13  X1	E02  X10
---	---	---	---














8	F35-C12  X5	F35-C14  X1	E02  X10
---	---	---	---












9	F35-C06  X1	F35-C07  X2	E02  X4
---	--	--	---







10	 <p>X1</p>	 <p>X1</p>	<p>F35-C23</p>  <p>X2</p>	<p>E02</p>  <p>X13</p>
----	---	---	---	---
















11	 x1	 x1	F35-C22  x2	E02  x26
----	---	---	---	---









12	 X1	 X1	 X1	 X1	 X1	 X40
----	---	---	---	---	---	--







1



2











3





F35-A01



26










E02









E02




29






13	F35-C31  X1	F35-C32  X1	F35-C33  X1	E02  X9
----	--	--	---	--










F35-C17






E02







15	 X1	F35-C18  X2
----	--	---







Please use rubber knife to help C17/C18 stick into the wall board










E02



E02




18	F35-C30  X4	E02  X26
----	--	---




19

F35-C25




X1

F35-C26





X1


E02



X4



E02




20

F35-C04



X1

F35-C05




X4

F35-A04




X2

F35-A05







X1




F35-A06







X1






21	F35-C29  X4	E01  X16	E02  X8
----	--	---	--




22	F35-D01  X3	E01  X18
----	--	---






23

F35-D02




X1

E01



X4





24

E03







X24



E03



42

25	F35-A08  X1	E02  X6
----	--	--






ATTENTION!!

When the door is not vertical or parallel after installation, please make appropriate adjustments according to the following figure



1.loosen the screws



2.If the door corner is tilted upward, press the corner with your hand, pull it upward slightly, and lock screws



3.If the door corner is tilted down, hold the corner with your hand, pull it upward slightly, and lock screws



BASEMENT EXPANSION SCREWS ASSEMBLY

