


ASSEMBLY INSTRUCTION











MORA LOUNGE SET NATURAL




WF281655
WF281656

Notice:


1. 50% Tighten before fixing all screws, Allen wrench is recommended instead of an electric drill.
2. Place the item on a flat ground to adjust and make sure it remains stable.
3. Tighten up all screws with tools gradually.
4. If the screws are not aligned with holes during assembly, please loosen all the other screws to 50% and continue the assembly process.
5. If the item is not stable, please loosen all the screws, adjust it on a flat ground and tighten up all screws again.
6. Note: If one or some screws are fully tightened during assembly, chances are the others will not be aligned with holes. In addition, all the holes are designed to be relatively larger to provide more space for the adjustment of the screws




BOX 1/2




1230x600x45 mm




815x555x135 mm




600x260x50 mm




1230x600x60 mm




710x255x25 mm




550x500x30 mm




550x500x60 mm




560x370x60 mm




815x545x5 mm




1130x500x60 mm




1235x255x30 mm




1135x260x50 mm




BOX 2/2




1130x500x30 mm




1135x710x95 mm




710x560x95 mm




710x560x95 mm




550x260x30 mm




510x260x25 mm




565x545x60 mm




565x545x60 mm



550x460x120 mm





565x545x60 mm




565x545x60 mm

Notice:






1. **50% Tighten before fixing all screws, Allen wrench is recommended instead of an electric drill.**
2. **Place the item on a flat ground to adjust and make sure it remains stable.**
3. **Tighten up all screws with tools gradually.**
4. **If the screws are not aligned with holes during assembly, please loosen all the other screws to 50% and continue the assembly process.**
5. **If the item is not stable, please loosen all the screws, adjust it on a flat ground and tighten up all screws again.**
6. **Note: If one or some screws are fully tightened during assembly, chances are the others will not be aligned with holes. In addition, all the holes are designed to be relatively larger to provide more space for the adjustment of the screws.**







1









2

E x 8	C x 12	J x 4	H x 1	K x 1	
					
M6x40 mm	Ø16x1 mm	M6x4 mm	4 mm	25x88x2 mm	








3

F x 4  M6x55 mm	G x 4  50x50x65 mm	H x 1  4 mm	
--	---	--	--













4












5







A x 2	C x 4	E x 2	H x 1	
				
M6x90 mm	Ø16x1 mm	M6x40 mm	4 mm	


	A	D	F	E	B
					
	M6x90 mm	M6x60 mm	M6x55 mm	M6x40 mm	M6x30 mm






6




C x 6	D x 2	E x 2	J x 2	H x 1	K x 1
					
Ø16x1 mm	M6x60 mm	M6x40 mm	M6x4 mm	4 mm	25x88x2 mm

	A	D	F	E	B
					
	M6x90 mm	M6x60 mm	M6x55 mm	M6x40 mm	M6x30 mm





7

C x 4  Ø16x1 mm	E x 4  M6x40 mm	H x 1  4 mm	
--	--	--	--








8

H x 1  4 mm	
--	--








9

F x 4  M6x55 mm	G x 4  50x50x65 mm	H x 1  4 mm	
--	---	--	--













10












11







A x 1  M6x90 mm	C x 2  Ø16x1 mm	E x 1  M6x40 mm	H x 1  4 mm	
--	--	--	---	--


	A  M6x90 mm	D  M6x60 mm	F  M6x55 mm	E  M6x40 mm	B  M6x30 mm
---	--	--	--	--	--






12







C x 5  Ø16x1 mm	D x 1  M6x60 mm	E x 3  M6x40 mm	J x 1  M6x4 mm	H x 1  4 mm	K x 1  25x88x2 mm
--	--	--	---	--	--



	A  M6x90 mm	D  M6x60 mm	F  M6x55 mm	E  M6x40 mm	B  M6x30 mm
---	--	--	--	--	--







13



B x 3  M6x30 mm	C x 3  Ø16x1 mm	H x 1  4 mm	
--	--	--	--

	 A	 D	 F	 E	 B
	M6x90 mm	M6x60 mm	M6x55 mm	M6x40 mm	M6x30 mm





14





B x 1  M6x30 mm	C x 4  Ø16x1 mm	E x 3  M6x40 mm	H x 1  4 mm	
--	--	--	---	--




15





16










17













18

A x 1  M6x90 mm	C x 2  Ø16x1 mm	E x 1  M6x40 mm	H x 1  4 mm	
--	--	--	---	--










19

C x 4  Ø16x1 mm	D x 1  M6x60 mm	E x 2  M6x40 mm	J x 1  M6x4 mm	H x 1  4 mm	K x 1  25x88x2 mm
--	--	--	---	--	--










20

B x 1  M6x30 mm	C x 4  Ø16x1 mm	E x 3  M6x40 mm	H x 1  4 mm	
--	--	--	---	--









21

B x 1  M6x30 mm	C x 3  Ø16x1 mm	E x 2  M6x40 mm	H x 1  4 mm	
--	--	--	---	--





22

B x 2  M6x30 mm	C x 4  Ø16x1 mm	E x 2  M6x40 mm	H x 1  4 mm	
--	--	--	---	--








23

H x 1  4 mm	
--	--



24

F x 5  M6x55 mm	G x 5  50x50x65 mm	H x 1  4 mm	
--	---	--	--



25

