












Installation Manual



Detailed Diagram of Shower Door Components



PARTS LIST.

1		2		3		4		5		6	
TOP TRACK (1 pcs)		BOTTOM TRACK (1 pcs)		WALL JAMB (2 pcs)		DOOR PANEL (2PCS) (INSIDE / OUTSIDE)		WALL BUMPER (2 Pcs)		PANEL GUIDE (1 Pcs)	
7		8		9		10		11		12	
ROLLER (4 Pcs)		1 1/2" SCREW (6pcs)		WALL PLUG (6 pcs)		3/8" SCREW (2 pcs)					

Before You Start

Thank you for choosing Nivéál® frameless sliding shower door. We hope to provide you with the most satisfying product and user experience.

Please read through this manual carefully as it contains important product information and step-by-step instructions on how to install this product. Fail to follow certain conditions of the instruction may affect the warranty of the product.











- 1.** Prior to installation, please inspect boxes for damages due to shipping. If there is any missing part or defecting part, please contact customer service through e-mailing to info@lifeupinc.net within 7 business days of delivery date. Please note that Nivéál® will not replace any damaged products or missing parts free of charge after 7 business days of installation of the product. Feel free to contact Nivéál® if you have any question with your PO number.
- 2.** Please make sure to contact your local building codes with questions on installation standards. Building and plumbing codes may vary by location.
- 3.** Please check that the installation surfaces or level is strong enough to support the weight of the shower door. Do not install it to plastic shower modules or drywall unless additional support is provided behind the wall.
- 4.** This shower door is very heavy and requires professional installation.



Warnings

- 1.** Always wear safety glasses while cutting or drilling.
- 2.** Unframed tempered glass should never contact rigid surfaces, or it may shatter. Do not touch the edge of the tempered glass panel with tools or any rigid object. Do not set the unframed tempered glass edge directly on the floor.
- 3.** Do not attempt to cut tempered glass, or it will shatter.


Required Tools:

1 	2 	3 	4 	5 
SILICONE	DRILL	MEASURE TAPE	RUBBER MALLET	DRILL BITS
6 	7 	8 	9 	10 
LEVEL	PENCIL	SCREW DRIVERS	HANDSAW	SAFETY GLASSES

STEP 1


Attach rollers to flange at top of both panels. The outer panel has an offset lip on one side of the bottom frame. This lip is on the outside face of the panel and rollers should be mounted on the same side as the lip. The inner panel has holes drilled on one side only of the bottom frame. The holes are on the inside face of the panel and the rollers should be mounted on the same side as the holes.

NOTE: The slots in the top flange are used to fine tune the adjustment of the panel to make up for walls that are slightly out of square or plumb. For best results start with all rollers centered in the slot and then make adjustments as needed..



STEP 2

Measure opening on bottom and cut Bottom track ② 1 1/2" shorter than opening.



STEP 3


Place wall jamb down over bottom track so that the back of the jamb is between the bottom track and the wall. Using a level to insure jamb is plumb, mark hole locations. Remove jamb and drill holes about 1 1/2" deep at each of the marked locations.



NOTE: When drilling into ceramic, glass or stone use a 1/4" MASONRY drill bit. **When installing on fiberglass or acrylic use a 1/8" drill bit and discard the wall plugs.** When installing on Fiberglass or Acrylic the side jambs may need to be filed at the bottom to fit the contour of the unit.

STEP 4

Repeat Step 3 on the other side.




STEP 6

Push wall plugs into holes drilled in step 3 and tap them in with a rubber mallet.

NOTE: If you are installing on fiberglass or acrylic, skip this step and discard the wall plugs.

STEP 5

Run a thin bead of silicone caulk down the entire length of both bottom ledges on the bottom track. Place the bottom track into position and press down firmly along the length of the track.



STEP 7

Dab silicone into all 3 holes on each side. Run 1 1/2" Screws to attach wall jamb to wall in top and bottom holes only on both sides. The center hole will be addressed in the next step.





⑧ 1 1/2" SCREW

Run 1 1/2" screws through wall bumper and then drive it into center hole on each side.

Measure opening at top of wall jamb,
cut Top track ① 1/16" shorter than
opening.


Place Top track down over wall jams as shown.



Install outer door panel by lifting up & into Top track.

STEP 12



Install inner door panel by lifting up & into Top track.



STEP 13

Hook lip of bottom guide into slot in bottom track and screw it to inside door bottom using 3/8" screws.

NOTE: This system works best if there is a small amount of play between the guide and panel. We suggest that you tighten the screws down completely and then back them off 1/4 turn. Slide the door panel from end to end of the track. If it feels loose and sloppy, tighten down a bit more. If the panel does not slide smoothly along the entire track, back them off a bit more.



FINAL STEP: Caulk both sides of the shower door frame to seal. Keep the entire area dry for a minimum of **24** hours. Your installation is now complete. Thank you for choosing Foremost shower doors.