INSTALLATION AND SAFETY INSTRUCTIONS HC-549

FOR YOUR SAFETY

WARNING: BE SURE THE ELECTRICITY TO THE WIRES YOU ARE WORKING ON IS TURNED OFF; EITHER THE FUSE REMOVED OR THE CIRCUIT BREAKER SET AT OFF.


ASSEMBLY


1. Choose the connector base side to suit your application. Tap off connector:

One side: 10/2 to 16/2 or 12/2

Other side: 16/2 or 12/2 to 12/2 or 12/3

- 2. To use 12/3 break-off tabs.
- 3. Lay 2 or 3 conductor main cable into the connector base.
- 4. Align the notch from the connector cover with the groove on the connector base. Press connector halves together until contacts touch cable insulation.
- 5. Insert the other conductor cable into the connector base.
- 6. Attach connector halves with the two screws (included).





INSTALLATION AND SAFETY INSTRUCTIONS HC-549

FOR YOUR SAFETY

WARNING: BE SURE THE ELECTRICITY TO THE WIRES YOU ARE WORKING ON IS TURNED OFF; EITHER THE FUSE REMOVED OR THE CIRCUIT BREAKER SET AT OFF.

ASSEMBLY

Choose the connector base side to suit your application.
Tap off connector:

One side: 10/2 to 16/2 or 12/2

Other side: 16/2 or 12/2 to 12/2 or 12/3

- 2. To use 12/3 break-off tabs.
- 3. Lay 2 or 3 conductor main cable into the connector base.
- Align the notch from the connector cover with the groove on the connector base. Press connector halves together until contacts touch cable insulation.
- 5. Insert the other conductor cable into the connector base.
- 6. Attach connector halves with the two screws (included).

