

sander. Sandpaper without holes will not allow dust to enter the canister.

The hook and loop pad and individual bases are replaceable parts. If they become worn, contact your local service center. For more information call: **1-800-544-6986**.

⚠ WARNING: The use of any accessory not recommended for use with this tool could be hazardous.

Application / Accessory Matrix

| <u>ACCESSORY</u> | <u>RECOMMENDED APPLICATIONS / USES</u> |
|---------------------------------|--|
| MEDIUM GRIT SANDPAPER | PAINT, VARNISH, RUST REMOVAL |
| FINE GRIT SANDPAPER | SURFACE BLENDING AND FINISHING |
| EXTRA FINE GRIT SANDPAPER | SANDING BETWEEN COATS OF PAINT OR VARNISH |
| DETAIL SANDING TIPS | CORNERS / HARD TO REACH PLACES |
| 1 OT POLISHING / STRIPPING WOOL | POLISHING METALS / STRIPPING VARNISH OR URETHANE |
| 4 OT FINE POLISHING WOOL | FINE POLISHING, SATIN FINISH ON PAINT / VARNISH / URETHANE |
| GREY FOAM PAD | APPLYING AND REMOVING POLISH |
| WHITE NON-WOVEN PAD | LIGHT SCRUBBING |
| RED NON-WOVEN PAD | HEAVY SCRUBBING / RUST REMOVAL |

The pads described above may be available in kits where Mouse® products are sold. For more information call **1-800-544-6986**.

SERVICE INFORMATION

All Black & Decker Service Centers are staffed with trained personnel to provide customers with efficient and reliable power tool service. Whether you need technical advice, repair, or genuine factory replacement parts, contact the Black & Decker location nearest you. To find your local service location, refer to the yellow page directory under "Tools—Electric" or call: **1-800-544-6986** or visit **www.blackanddecker.com**

FULL TWO-YEAR HOME USE WARRANTY

Black & Decker (U.S.) Inc. warrants this product for two years against any defects in material or workmanship. The defective product will be replaced or repaired at no charge in either of two ways.

The first, which will result in exchanges only, is to return the product to the retailer from whom it was purchased (provided that the store is a participating retailer). Returns should be made within the time period of the retailer's policy for exchanges (usually 30 to 90 days after the sale). Proof of purchase may be required. Please check with the retailer for their specific return policy regarding returns that are beyond the time set for exchanges.

The second option is to take or send the product (prepaid) to a Black & Decker owned or authorized Service Center for repair or replacement at our option. Proof of purchase may be required. Black & Decker owned and authorized Service Centers are listed under "Tools-Electric" in the yellow pages of the phone directory and on our website

www.blackanddecker.com.

This warranty does not apply to accessories. This warranty gives you specific legal rights and you may have other rights which vary from state to state. Should you have any questions, contact the manager of your nearest Black & Decker Service Center. This product is not intended for commercial use.

LATIN AMERICA: This warranty does not apply to products sold in Latin America. For products sold in Latin America, check country specific warranty information contained in the packaging, call the local company or see the website for warranty information.

FREE WARNING LABEL REPLACEMENT: If your warning labels become illegible or are missing, call 1-800-544-6986 for a free replacement.

Black & Decker (U.S.) Inc.,
701 E. Joppa Rd.
Towson, MD 21286 U.S.A.



See 'Tools-
Electric'
– Yellow Pages –
for Service &
Sales

